



# X1-VAST

5 kW / 6 kW / 8 kW / 10 kW
User Manual

Version 1.0

www.solaxpower.com



# STATEMENT

## Copyright

Copyright © SolaX Power Network Technology (Zhejiang) Co., Ltd. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of SolaX Power Network Technology (Zhejiang) Co., Ltd.

### **Trademarks**

and other symbol or design (brand name, logo) that distinguishes the products or services offered by SolaX has been trademark protected. Any unauthorized use of the above stated trademark may infringe the trademark right.

#### **Notice**

Please note that certain products, features, and services mentioned in this document may not be within the scope of your purchase or usage. Unless otherwise specified in the contract, the contents, information, and recommendations presented in this document are provided "as is" by SolaX. We do not provide any warranties, guarantees, or representations, whether express or implied.

The content of the documents is reviewed and updated as needed. However, occasional discrepancies may occur. SolaX retains the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without prior notice.

The images included in this document are solely for illustrative purposes and may differ based on the specific product models.

For more detailed information, kindly visit the website of SolaX Power Network Technology (Zhejiang) Co., Ltd. at www.solaxpower.com.

SolaX retains all rights for the final explanation.

# **About This Manual**

## Scope of Validity

This manual is an integral part of X1-VAST series inverter. It describes the transportation, storage, installation, electrical connection, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

This manual is valid for the following inverter models:

- X1-VAST-5K
- X1-VAST-6K
- X1-VAST-8K
- X1-VAST-10K

### Model description



Item	Meaning	Description
1	Product family name	"X1-VAST": energy storage series inverter that supports grid connection of photovoltaic system;
2	Power	"5K": rated output power of 5 kW.

# **Target Group**

The installation, maintenance and grid-related setting can only be performed by qualified personnel who:

- Are licensed and/or satisfy state and local jurisdiction regulations.
- Have good knowledge of this manual and other related documents.

# Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description
<u> </u>	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
<b>!</b> WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION!	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE!	Provides tips for the optimal operation of the product.

# **Change History**

Version 01 (2025-03-11)

Updated "2.5 Working Principle" (Added Whole home backup for Australia)

Updated "10 Operation on LCD" (Added Whole Home Backup, WI-BR HP Mode, Meter1 config, Meter2 config, Reset Meter/CT\_1, Reset Meter/CT\_2)

Version 00 (2024-08-08)

Initial release

# **Table of Contents**

1	Sat	fety		1
	1.1	Gene	ral Safety	1
	1.2	Safety	y Instructions of PV, Inverter and Grid	1
		1.2.1	Safety Instructions of PV	2
		1.2.2	Safety Instructions of Inverter	2
		1.2.3	Safety Instructions of Utility Grid	3
2	Pro	oduct	Overview	4
	2.1	Produ	uct Introduction	4
	2.2	Appea	arance	4
	2.3	Suppo	orted Power Grid	6
	2.4	Symb	ols on the Label and Inverter	7
	2.5	Worki	ing Principle	8
		2.5.1	Circuit Diagram	8
		2.5.2	Application Schemes	9
	2.6	Worki	ing State	12
	2.7	Worki	ing mode	13
		2.7.1	Self Use Mode (Priority: Loads > Battery > Grid)	13
		2.7.2	Feed-in Priority (Priority: Loads > Grid > Battery)	15
		2.7.3	Backup Mode (Priority: Loads > Battery > Grid)	16
		2.7.4	Peak Shaving Mode	18
		2.7.5	TOU Mode	19
		2.7.6	EPS Mode (Priority: Loads > Battery)	20
		2.7.7	Manual Mode	21
		2.7.8	Export Control Function	21
3	Sys	stem (	Overview	22
4	Tra	nspo	rtation and Storage	25
5	Pre	eparat	tion before Installation	26
	5.1	Selec	tion of Installation Location	26
		5.1.1	Environment Requirement	26
		5.1.2	Installation Carrier Requirement	
			Clearance Requirement	
	5.2		Requirement	
			ionally Required Materials	

6	Un	packing and Inspection	32
	6.1	Unpacking	.32
		Scope of Delivery	
7		chanical Installation	
	7.1	Dimensions for mounting	.37
	7.2	Installation procedures	.38
8	Ele	ctrical Connection	41
	8.1	Overview of Electrical Connection	.42
		8.1.1 Terminals of Inverter	.42
		8.1.2 Cable Connections of Inverter	.43
	8.2	PE Connection	.46
	8.3	AC Connection	.49
	8.4	PV Connection	.54
	8.5	Battery/V2X Power Cable Connection	.58
	8.6	COM Communication Connection	.61
		8.6.1 Pin Assignment of COM Terminal	.61
		8.6.2 Meter/CT Connection	.62
		8.6.3 EVC/RTU485 Communication Connection	.65
		8.6.4 BMS Communication Connection	.66
		8.6.5 V2X Communication Connection	.67
		8.6.6 HEATPUMP Communication Connection	.67
		8.6.7 COM communication connection wiring procedure	.68
	8.7	PARALLEL and DRM Communication Connection	.72
		8.7.1 Pin Assignment of PARALLEL and DRM Terminal	.72
		8.7.2 Parallel Connection	
		8.7.3 DRM Connection (Applicable to AS/NZS 4777.2)	.73
		8.7.4 PARALLEL and DRM communication connection wiring procedure	.75
	8.8	Monitoring Connection	.78
		Cable protective cover installation (Australian version only)	
9		tem Commissioning	
	9.1	Checking before Power-on	.84
	9.2	Powering on the System	.84
10	Ор	eration on LCD	.86
	10.1	Introduction of Control Panel	.86
	10.2	Introduction of Menu Interface	.88
	10.3	System ON/OFF	.91
	10.4	I Work Mode	Q1

	10.5 System Status	93
	10.6 Parallel Status	95
	10.7 History Data	95
	10.8 Setting	97
	10.8.1 User Setting	97
	10.8.2 Advanced Setting	103
	10.9 About	122
11	Operation on SolaX App and Web	123
	11.1 Introduction of SolaXCloud	123
	11.2 Operation Guide on SolaXCloud App	123
	11.2.1 Downloading and Installing App	123
	11.2.2 Operation on the App	124
	11.3 Operations on SolaXCloud Webpage	124
12	Troubleshooting and Maintenance	125
	12.1 Power off	125
	12.2 Troubleshooting	125
	12.3 Maintenance	134
	12.3.1 Maintenance routines	134
	12.3.2 Upgrading Firmware	135
13	Decommissioning	137
	13.1 Disassembling the Inverter	137
	13.2 Packing the Inverter	140
	13.3 Disposing of the Inverter	140
14	Technical Data	141
15	Appendix	144
	15.1 Application of Generator	144
	15.1.1 Introduction of generator application	144
	15.1.2 Notice for generator application	144
	15.1.3 ATS control mode	144
	15.1.4 Dry contact mode	146
	15.2 Application of Adapter Box G2	149
	15.2.1 Introduction of Adapter Box G2 application	149
	15.2.2 Wiring connection diagram	149
	15.2.3 Communication connection with inverter	
	15.2.4 Settings for Adapter Box G2	
	15.3 Application of EV-Charger	152
	15.3.1 Introduction of EV-Charger application	152

	15.3.2	Wiring connection diagram	.152
	15.3.3	Communication connection with inverter	.153
	15.3.4	Setting for EV-Charger	.154
15.4	Applic	ation of DataHub	.155
	15.4.1	Introduction of DataHub application	.155
	15.4.2	Wiring connection diagram	.155
	15.4.3	Communication connection with inverter	.156
	15.4.4	Settings for DataHub	.157
15.5	Applic	ation of Micro-grid	.158
	15.5.1	Introduction of Micro-grid application	.158
	15.5.2	Wiring conenction diagram	.158
	15.5.3	Working modes	.159
	15.5.4	Cable connection (Hybrid inverter)	.159
	15.5.5	Cable connection (On-grid inverter)	.159
	15.5.6	Cable connection (Meter)	.160
15.6	Applic	ation of Parallel Function	.161
	15.6.1	Introduction of parallel application	.161
	15.6.2	Notice for parallel application	.161
	15.6.3	System wiring diagram	.162
	15.6.4	System wiring procedure	.163
	15.6.5	Settings for parallel connection	.165
15.7	Applic	ation of Meter/CT	.167
	15.7.1	CT/Meter Connection Scenarios	.167
	15.7.2	Connection of CT	.167
	15.7.3	Connection of Direct-connected Meter	.170
	15.7.4	Connection of CT-connected Meter	.173
	15.75	Connection of Two Meters	176

# 1 Safety

# 1.1 General Safety

The series inverter has been meticulously designed and thoroughly tested to comply with the relevant state and international safety standards. Nevertheless, like all electrical and electronic device, safety precautions must be observed and followed during the installation of the inverter to minimize the risk of personal injury and ensure a safe installation.

Please thoroughly read, fully comprehend, and strictly adhere to the comprehensive instructions provided in the user manual and any other relevant regulations prior to the installation of the inverter. This document does not replace and is not intended to replace any local, state, provincial, federal or national laws, regulations or codes applicable to the installation, electrical safety and use of the inverter.

SolaX assumes no responsibility for any consequences resulting from the violation of the storage, transportation, installation and operation regulations outlined in this document. Such consequences include, but are not limited to:

- Inverter damage caused by force majeure events, such as earthquakes, floods, thunderstorms, lightning, fire hazards, volcanic eruptions, and similar events.
- Inverter damage due to human causes.
- Inverter damage caused by strong vibrations from external factors before, during and after installation.
- Use or operation of the inverter in violation of state and local policies or regulations.
- Failure to comply with the operation instructions and safety precautions provided with the product and in this document.
- Improper installation or use of the inverter in unsuitable environmental or electrical conditions.
- Unauthorized modifications to the product or software.
- Inverter damage occurring during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning performed by unauthorized personnel who lack the necessary licenses or do not comply with state and local regulations.

# 1.2 Safety Instructions of PV, Inverter and Grid

Save these important safety instructions. Failure to follow these safety instructions may result in damage to the inverter and injury or even loss of life.

### 1.2.1 Safety Instructions of PV

# **!** DANGER!

### Potential risk of lethal electric shock associated with the photovoltaic (PV) system

- Exposure to sunlight can result in the generation of high DC voltage by PV modules, which can lead to electric shock causing severe injuries or even death.
- Never touch the positive or negative poles of the PV connecting device, and avoid touching both poles simultaneously.
- Do not ground the positive or negative poles of the PV modules.
- Only qualified personnel can perform the wiring of the PV modules.

# **!** WARNING!

- Overvoltage protection with surge arresters should be provided when the PV system is installed. The inverter is fitted with SPDs on both PV input side and MAINS side.
- Please consult professionals before installing SPDs.

# **!** WARNING!

- Make sure that the input DC voltage does not exceed the maximum DC input voltage specified for the inverter. Overvoltage can cause irreversible damage to the inverter, and such damage is not covered by the warranty.
- PV modules should have an IEC61730 class A rating.

### 1.2.2 Safety Instructions of Inverter

# ♠ DANGER!

#### Potential risk of lethal electric shock associated with the inverter

- Only operate the inverter if it is in a technically faultless condition. Operating a faulty inverter may lead to electric shock or fire.
- Do not attempt to open the enclosure without authorization from SolaX.
   Unauthorized opening of the enclosure will void the warranty and can result in lethal danger or serious injury due to electric shock.
- Make sure that the inverter is reliably grounded before any operation to prevent the risk of electric shock causing lethal danger or serious injury.
- Only qualified personnel can perform the installation, wiring, maintenance of the inverter by following this document and the related regulations.

# **!** WARNING!

- During operation, avoid touching any parts of the inverter other than the DC switch and LCD panel (if any).
- Never connect or disconnect the AC and DC connector while the inverter is running.
- Prior to conducting any maintenance, turn off the AC and DC power and disconnect them from the inverter. Wait for 5 minutes to fully discharge the energy.

2

# **!** WARNING!

### Potential danger of scalding due to the hot enclosure of the inverter

 Avoid touching the inverter while it is running, as it becomes hot during operation and may cause personal injuries.

# / WARNING!

 When handling the battery, carefully follow all safety instructions provided in the battery manual. The battery used with the inverter must meet the specified requirements of the series inverter.

# **∕!**\ WARNING!

 Use insulated tools when installing the device, and always wear personal protective equipment during installation and maintenance.

# **!** CAUTION!

- Make sure that children are supervised to prevent them from playing with the inverter.
- Pay attention to the weight of the inverter and handle it properly to avoid personal injuries.

#### NOTICE!

- The inverter has an integrated Type-B Residual Current Monitoring Unit (RCMU). If an
  external Residual Current Device (RCD) is required by local regulations, verify the type
  of RCD required. It is recommended to use a Type-A RCD with a rating of 300 mA.
  When required by local regulations, the use of a Type-B RCD is permitted.
- Keep all product labels and the nameplate on the inverter clearly visible and well-maintained.

### 1.2.3 Safety Instructions of Utility Grid

#### NOTICE

 Only connect the inverter to the grid with the permission of the local utility grid company.

# 2 Product Overview

### 2.1 Product Introduction

The X1-VAST series is an energy storage PV grid-connected inverter. It supports various intelligent solutions such as load management, Meter/CT, dual battery terminals, microgrid, etc. to achieve efficient and economical energy utilization. The X1-VAST series inverter can be used with different capacities of SolaX battery.

# 2.2 Appearance




Figure 2-1 Appearance

Table 2-1 Description of appearance

Item	Description
Nameplate	Nameplate clearly identifies the device type, serial number, specific DC / AC parameters, certification, etc.

LCD panel	Including screen, indicators and keys. Screen displays the information; indicators indicate the status of inverter. Keys are used to perform the parameter setting.
DC switch	Disconnect the DC input when necessary.
Electrical connection area	Including PV terminals, battery and V2X terminals, grid terminals, EPS terminals, communication terminals, etc.

# 2.3 Supported Power Grid

There are different ways of wiring for different grid systems. TT / TN-S / TN-C-S are shown as below:




Figure 2-2 Supported power grid-TT




Figure 2-3 Supported power grid-TN-S




Figure 2-4 Supported power grid-TN-C-S

# 2.4 Symbols on the Label and Inverter

Table 2-2 Description of symbols

Symbol

Description



CE mark.

The inverter complies with the requirements of the applicable CE quidelines.



TUV certified.



RCM mark.

The inverter complies with the requirements of the applicable RCM quidelines.



Additional grounding point.



Beware of hot surface.

Do not touch a running inverter, as the inverter becomes hot during operation!



Risk of electric shock.

High voltage exists after the inverter is powered on!



Risk of danger.

Potential hazards exist after the inverter is powered on!



Read the enclosed documentations.



Do not dispose of the inverter together with household waste.



Do not operate this inverter until it is isolated from battery, mains and onsite PV generation source.





Danger of high voltage.

Do not touch live parts for 5 minutes after disconnection from the power sources.

# 2.5 Working Principle

# 2.5.1 Circuit Diagram

The inverter is equipped with multi-channel MPPT for DC input to ensure maximum power even under different photovoltaic input conditions. The inverter unit converts direct current into alternating current that meets the requirements of the power grid and feeds it into the power grid. The principle design of inverter is shown in the figure below:




Figure 2-5 Circuit diagram for X1-VAST series inverter

#### NOTICE!

MPPT 4 is available for 8 kW and 10 kW inverters.

# 2.5.2 Application Schemes




Figure 2-6 Partial home backup for Europe

#### NOTICE!

• The inverter supports Meter or CT connection. Here is taken CT connection as an example.




Figure 2-7 Partial home backup for Australia

#### NOTICE!

• The inverter supports Meter or CT connection. Here is taken CT connection as an example.




Figure 2-8 Whole home backup for Australia

#### NOTICE!

- When the whole home backup is used, the inverter does not need to connect CT or electricity meter, but it needs to be enabled in the LCD settings. (Setting path:
   Advance Setting > Whole Home Backup > Enable) The manual changeover switch goes to the EPS when the machine is in normal operation and to the grid when the machine is faulty and taken away for maintenance.
- PV4 is available for 8 kW and 10 kW inverter.

# 2.6 Working State

The series inverter has Waiting, Checking, Normal, Normal (R), EPS Checking, EPS, Fault, Idle and Standby state.

Table 2-3 Description of working state

State	Description
Waiting	<ul> <li>The inverter is waiting for the conditions to be met in order to enter Checking state.</li> </ul>
Checking	The inverter is checking for conditions to enter Normal state.
Normal	The inverter is working normally.
Normal (R)	The inverter is in VPP control state (remote control).
EPS Checking	The inverter is checking for conditions to enter EPS state.
EPS	The inverter is working in off-grid state.
Fault	The inverter detects error and prompts error code.
Idle	<ul> <li>When the battery SOC reaches the minimum SOC and there is no sufficient PV input voltage, the battery goes into hibernation and the inverter enters Idle state.</li> </ul>
Standby	<ul> <li>When the power of load is extremely low and there is no sufficient PV input voltage, or a state when the battery SOC is larger than or equal to 10% and there is no sufficient PV input voltage, the inverter enters Standby state.</li> <li>In this state, it detects PV connection, load power, etc to determine whether to exit Standby state and enter Normal state.</li> </ul>

### Working state of TOU mode

Table 2-4 Description of working state

State	Description
Normal (TOU-S)	• The inverter is in the Selfuse control state in TOU mode.
Normal (TOU-C)	The inverter is in the Charging control state in TOU mode.
Normal (TOU-D)	• The inverter is in the Discharging control state in TOU mode.
Normal (TOU-B)	The inverter is in the Battery off control state in TOU mode.
Normal (TOU-P)	The inverter is in the PeakShaving control state in TOU mode.

# 2.7 Working mode

Six working modes are available for you to choose in on-grid status, i.e Self use, Feed-in priority, Backup, Peak shaving, TOU and Manual. You can choose the working modes according to your lifestyle and environment.

When the power supply from the electric power company is stopped due to a power outage, it automatically switches to EPS mode and connects to the distribution board for a specific load, thereby providing power to important electrical appliances.

For how to set the working mode, please refer to the section "10.7.1 User Setting".

### 2.7.1 Self Use Mode (Priority: Loads > Battery > Grid)

The self use mode is suitable for areas with low feed-in subsidies and high electricity prices. The power of PV will supply the loads first, and the surplus power will charge the battery, then the remaining power will feed into the grid.




Figure 2-9 Self Use mode

Table 2-5 Description of self use mode

Time period	Inverter working status
Forced charging period	<ul> <li>Charge the battery first untill the battery SOC reaches the specified Charge battery to value. You can configure the inverter to either draw power from the grid or not.</li> </ul>

Time period	Inverter working status
Allowed discharging period	PV is sufficient (PV → load → battery → grid)  • The power generated from PV prioritizes supplying the load. Any excess power is then directed towards charging the battery, and if there is still surplus electricity, it can be sold to the grid. In the event that the local utility restricts the sale of electricity to the grid, the Export Control value can be set on the inverter. Please refer to "Setting Export Control".
	PV is insufficient (PV+battery → load) • The battery discharges power to the load, and once its capacity reaches <b>Min SOC</b> , it automatically ceases discharging.

#### Note:

**Charge battery to**: The battery SOC charged from grid. 10% by default, the settable range is 10%-100%.

**Min SOC**: Minimum SOC of the battery under grid connection. 10% by default, the settable range is  $10\%\sim100\%$ .

**Export Control**: The power exported to the grid. 60000 W by default, the settable range is  $0 \sim 60000 \text{ W}$ .

### Charge & Discharge Period

You can set two configurable working periods: forced charging period and allowed discharging period. The interval not in the charging  $\vartheta$  discharging period belongs to other time periods.

• Forced charging period (Default period: 00:00~00:00, closed by default)

In the forced charging period, the inverter will charge the battery first untill the battery SOC reaches the specified **Charge battery to** value set in each working mode. You have the option to configure the inverter to either draw power from the grid or not.

Allowed discharging period (Default period: 00:00~23:59)

In the allowed discharging period, the inverter will allow the battery to discharge and charge power in accordance with the working mode and load conditions.

Period not set as forced charging or allowed dicharging period

In this period, the inverter will allow the battery to charge but can not discharge power.

#### NOTICE

 The charging and discharging period is only applicable for self-use mode, feed-in priority and backup mode. The priority of forced charging period is higher than all working modes.

## 2.7.2 Feed-in Priority (Priority: Loads > Grid > Battery)

The feed-in priority mode is suitable for areas with high feed-in subsidies. The power generated from PV is directed towards supplying the loads. Any excess power beyond the load requirements will be fed into the grid.




Figure 2-10 Feed-in priority

Table 2-6 Description of feed-in priority

Time period	Inverter working status
Forced charging period	<ul> <li>Charge the battery first untill the battery SOC reaches the specified Charge battery to value. You can configure the inverter to either draw power from the grid or not.</li> </ul>
Allowed discharging period	PV is sufficient (PV → load → grid) • The power generated from PV is directed towards supplying the loads. Any excess power beyond the load requirements will be fed into the grid.
	PV is insufficient (PV+battery → load) • PV and battery supply power to the load at the same time, and once the battery capacity reaches <b>Min SOC</b> , it automatically ceases discharging.

#### Note:

**Charge battery to**: The battery SOC charged from grid. 50% by default, the settable range is  $10\%\sim100\%$ .

Min SOC: Minimum SOC of the battery under grid connection. 10% by default, the settable

range is 10%~100%.

#### NOTICE

- You can set two configurable working periods: forced charging period and allowed discharging period. Please refer to "Charge & Discharge Period" for details.
- In feed-in priority mode, considering whether the battery can be charged during the daytime. If not, it is recommended to set forced charging period during off-peak hours.

### 2.7.3 Backup Mode (Priority: Loads > Battery > Grid)

The backup mode is suitable for areas with frequent power outages.

This mode will maintain the battery capacity at relatively high level to ensure that the emergency loads can be used when the grid is off. Same working logic with self-use mode.




Figure 2-11 Backup mode

Table 2-7 Description of backup mode

Time period	Inverter working status
Forced charging period	<ul> <li>Charge the battery first untill the battery SOC reaches the specified Charge battery to value. You can configure the inverter to either draw power from the grid or not.</li> </ul>

Time period	Inverter working status
Allowed discharging period	<ul> <li>The working logic remains the same as for self-use mode. The difference lies in:</li> <li>In self use mode, the battery goes into hibernation when PV input is not available and the battery SOC reaches Min SOC (on-grid min SOC). In the event of a grid outage, the inverter will not enter EPS mode.</li> <li>In backup mode, the inverter enters a standby state when PV input is not available and the battery SOC reaches Min SOC (on-grid min SOC). In the event of a grid outage, it will switch to EPS mode until the battery discharges to Min SOC (Off-grid min SOC).</li> </ul>

#### Note:

**Min SOC** (on-grid min SOC): Minimum SOC under grid connection. 10% by default, the settable range is  $10\% \sim 100\%$ .

**Min SOC** (off-grid min SOC): Minimum SOC under off-grid conditions. 30% by default, the settable range is  $10\% \sim 100\%$ .

#### NOTICE

- You can set two configurable working periods: forced charging period and allowed discharging period. Please refer to "Charge & Discharge Period" for details.
- If there is a foreseeable power outage, switch from other working modes to the backup mode in advance.

### 2.7.4 Peak Shaving Mode

Peak shaving mode is set for leveling out peaks in electricity use. The system is intelligently controlled to ensure charging takes place during off-peak hours and discharging occurs during peak hours.




Figure 2-12 Peakshaving mode

Table 2-8 Description of peakshaving mode

Time Period	Inverter working status
Period A	<ul> <li>The grid can charge the battery to MaxSOC within the set ChargePowerLimits. In this period, the battery will not discharge power.</li> </ul>
Period B & D	Grid consumption power < <b>PeakLimits</b> (PV+grid → load)  • The PV and grid will power the load. The battery will not charge or discharge power.
	Grid consumption power > PeakLimits (PV + battery+grid → load)  • The battery will discharge energy for loads and thus reduce the amount of energy purchased from the grid.
Period C	<ul> <li>(PV → battery → load → grid)</li> <li>The battery does not discharge power. The PV charges the battery up to the <b>Reserved SOC</b> before supplying power to the loads. Any excess power beyond the load requirements is fed into the grid.</li> </ul>

#### Note:

**MaxSOC:** The energy taken from grid to charge the battery. 50% by default, the settable range is 10%-100%.

**ChargePowerLimits**: The charging power from grid. 8000 W by default, the settable range is 0-8000 W.

**PeakLimits**: The load consumption power from grid side. 0 W by default, the settable range: 0-60000 W.

**Reserved SOC**: The lower limit of battery SOC required for later peak shaving period. 50% by default, the settable range is  $10\sim100\%$ .

#### 2.7.5 TOU Mode

In the TOU mode, different working modes, i.e Self Use, Charging, Discharging, Peaking shaving and Battery off can be set for different time periods in accordance with actual needs and environment conditions through SolaX Cloud App or Web.

The day can be divided into up to 24 time slots, and the minimum time slot is 15 minutes, independent working mode can be set for each time slot. Please refer to Web Guide or App Guide for details about how to set the TOU mode.

Time Slot	Working Mode
X:XX~X:XX	Choose one mode from Self-use / Charging / Discharging /
(e.g 0:00~0:15)	Battery off / Peaking shaving

#### Note:

Self Use: Same working logic with "Self Use Mode", but it is not limited by the charging and discharging time slots. The priority of PV: Loads > Battery > Grid.

Charging: The power of PV will charge the battery as much as possible to the set SOC of **Charge BAT to** (%). You can set whether to Charge from grid. The default value of **Charge BAT to** (%) is 100%. When the battery reaches the set SOC, the surplus power will perform "Self-use Mode" or supply to the grid (based on the system setup), at this point, Charge from grid is not allowed.

Discharging: If allowed by the battery, the system outputs a specified power from the battery based on the set output percentage, controlling the power at the AC port. You need to set the **Rate of AC Power** (%) through Web or App when choosing Discharging mode. When the battery **Discharge to** (%) reaches the set SOC, the inverter performs "Self Use Mode".

Peak shaving: The working logic is that when the power consumption from the grid exceeds the set PeakLimit value, the battery is allowed to discharge power. The excess power beyond the limit is provided by the combination of photovoltaic and battery to ensure that the maximum power purchased from the grid does not exceed the set limit. You need to set the PeakLimit value through Web or App when choosing Peak shaving mode

Battery off: The battery neither charges nor discharges. The power of PV will supply to loads or the grid. Only when the battery SOC is lower than the system (TOU) Min SOC, the battery can be charged.

### 2.7.6 EPS Mode (Priority: Loads > Battery)

During a power failure, the system will provide uninterrupted power supply to the EPS loads using the power from PV and the battery. It is important to ensure that the EPS loads should not exceed the maximum output power of the battery.




Figure 2-13 EPS mode

Table 2-9 Description of EPS mode

PV is sufficient
<ul> <li>(PV → load → battery)</li> <li>The PV prioritizes supplying power to the load, with any excess energy being directed towards charging the battery.</li> </ul>
PV is insufficient (PV+battery → load) • The PV prioritizes supplying power to the load. If the energy is not enough, the battery will discharge power until the battery SOC reaches Min SOC and then error of BatPowerLow will be reported.
The inverter reports <b>BatPowerLow</b> . When there is PV, it will charge the battery first. After charging to the set <b>Min ESC SOC</b> value, it will be automatically recovered and enter EPS mode again.

#### Note:

**Min SOC**: Minimum SOC of the battery under off-grid conditions. 10% by default, the settable range: 10%-100%.

**Min ESC SOC**: The minimum SOC required for re-entry EPS mode. 30% by default, the settable range: 15%-100%.

### 2.7.7 Manual Mode

This working mode is only for the qualified personnel to perform debugging and maintenance. It includes **Forced Discharge**, **Forced Charge** and **Stop Chg&Dischrg**. The system will restore to the original working mode after six hours **Manual** mode is set.

### 2.7.8 Export Control Function

Solar export control is a limit on the amount of energy your solar system can export into the grid. You need to connect the meter or CT and correctly set the grid-connected power control limit through the inverter (setting range:  $0W\sim6000W$ ). When the system is in parallel, set this parameter on the master inverter.

# 3 System Overview

### **System Overview**




Figure 3-1 System diagram

#### NOTICE

• The system diagram is for illustration only, please be subject to the actual situation.

Table 3-1 System item description

	- Table 6 1 Gyatam Ram desamption
Item	Description
X1-VAST series (the device covered in this manual)	The X1-VAST series is an energy storage inverter that supports grid connection of a photovoltaic system.
PV modules	PV modules work in MPPT mode. The maximum number of MPPT is two for 5 kW and 6 kW inverters and three for 8 kW and 10 kW inverters.
Battery	The series inverter should be coupled with lithium-ion battery. It communicates with the inverter via BMS and must comply with the specifications of the regulations.
Meter/CT	The meter/CT is used by the inverter for import / export or consumption readings, and manages the battery charge / discharge accordingly for smart energy management applications. Wireless meter solution is supported.
Additional on- grid inverter (supported)	The series inverter supports micro-grid function that makes hybrid inverter simulate the grid to active on-grid inverter during offgrid period by connecting on-grid inverter to hybrid inverter's EPS terminal. Please refer to "15.5 Application of Micro-grid" for specific wiring and setting.
Adapter Box G2 (supported)	With SolaX Adapter Box G2, you can connect the smart heat pump to the energy storage systems, realizing the control of the heat pump through inverter. Please refer to "15.2 Application of Adapter Box G2" for specific wiring and setting.
DataHub (supported)	SolaX DataHub is a professional device that for monitoring platforms of photovoltaic power generation systems, which enables data collection, storage, output control, centralized monitoring, and centralized maintenance of devices such as inverters, electricity meters, and environmental monitoring instruments in photovoltaic power generation systems. Please refer to "15.4 Application of DataHub" for specific wiring and setting.
EV-Charger (supported)	The series inverter can communicate with SolaX EV-Charger to form an intelligent photovoltaic, storage and EV charging energy system, thus maximizing the utilization of photovoltaic energy. Please refer to "15.3 Application of EV-Charger" for specific wiring and setting.
Generator (supported)	SolaX PV-Genset solution ensures optimum interaction between the photovoltaics and diesel generator, which saves fuel, lowers energy costs and ensures a stable and reliable power supply. Please refer to "15.1 Application of Generator" for specific wiring and setting.

### System Overview

Item	Description
Grid	220 V / 230 V and 240 V grid are supported.
SolaX Cloud	SolaX Cloud is an intelligent, multifunctional monitoring platform that can be accessed either remotely or through a hard wired connection. With the SolaX Cloud, the operators and installers can always view key and up to date data.

# 4 Transportation and Storage

If the inverter is not put into use immediately, the transportation and storage requirements need to be met:

### Transportation

- The inverter must be transported in its original packaging. SolaX will not be held responsible for any damage to the inverter caused by improper transportation or by transportation after it has been installed.
- Observe the caution signs on the packaging of inverter before transportation.
- Pay attention to the weight of the inverter. Carry the inverters by the required number of personnel as specified by local regulations.(gross weight of X1-VAST: 35 kg)
- Wear protective gloves when carrying the equipment by hand to prevent injuries.
- When lifting up the inverter, hold the handle position and the bottom position of the carton. Keep the inverter horizontal in case of falling down.



Figure 4-1 Caution signs on the packaging

### Storage

- The inverter must be stored indoors.
- Do not remove the original packaging material and check the outer packaging material regularly.
- The storage temperature should be between -40°C and +65°C. The relative humidity should be between 4%RH and 100%RH.
- Stack the inverter in accordance with the caution signs on the inverter carton to prevent their falling down and device damage. Do not place it upside down.

# 5 Preparation before Installation

#### 5.1 Selection of Installation Location

The installation location selected for the inverter is quite critical in the aspect of the guarantee of machine safety, service life and performance. It has the IP66 ingress protection, which allows it to be installed outdoor. The installation position shall be convenient for wiring connection, operation and maintenance.


### 5.1.1 Environment Requirement


Make sure the installation environment meets the following conditions:

- The ambient temperature: -35°C to +60°C.
- The relative humidity shall be between 4-100%RH.
- Do not install the inverter in the areas where the altitude exceeds 3000 m.
- Install the inverter in a well-ventilated environment for heat dissipation. It is recommended to install an awning over the inverter if it is installed on a support outdoor.
- Do not install the inverter in areas with flammable, explosive and corrosive materials or near antennas.
- Avoid direct sunlight, rain exposure and snow accumulation.

















#### NOTICE

- For outdoor installation, precautions against direct sunlight, rain exposure and snow accumulation are recommended.
- Exposure to direct sunlight raises the temperature inside the device. This temperature rise poses no safety risks, but may impact the device performance.
  - Install the inverter at least 500 meters away from the coast and avoid sea breeze directly hit.




Figure 5-1 Recommended installation position




Figure 5-2 Incorrect installation position

#### NOTICE!

• For the installation of the whole system, please refer to the specific environment requirement of each unit.

### 5.1.2 Installation Carrier Requirement

The installation carrier must be made of a non-flammable material, such as solid brick, concrete, etc. and be capable of supporting the weight of the inverter and suitable of the dimensions of the inverter. If the wall strength is not enough (such as wooden wall, the wall covered by a thick layer of decoration), it must be strengthened additionally.




Figure 5-3 Installation carrier requirement

#### NOTICE!

• Please take the weight of battery into account when wall-mouting the whole system.

#### 5.1.3 Clearance Requirement

When planning installation space, it is important to consider the bending radius of the wires.

To guarantee proper heat dissipation and ease of disassembly, the minimum space around the inverter must meet the standards indicated below.

For installations with multiple inverters, make sure to leave a minimum space of 30 cm between each inverter. In areas with high ambient temperatures, increase the clearances between the inverters and provide adequate fresh air ventilation if feasible.




Figure 5-4 Clearance requirement for single inverter





Figure 5-5 Clearance requirement for multiple inverters

## 5.2 Tools Requirement

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site. Please note that the tools used must comply with local regulations.




















































## 5.3 Additionally Required Materials

Table 5-1 Additionally required wires

No.	Required Material		Туре		Conductor Cross-section
1	PV wire	Q	Dedicated PV wire w rating of 600 V	vith a voltage	6 mm²
2	Communication wire		Network cable CAT	Network cable CAT5e	
3	Grid wire		Three-core copper	Three-core copper cable 16	
4	EPS wire		Two-core copper of (select two-core of cable according to not)	r three-core	16 mm²
5	Additional PE wire		Conventional yello wire	w and green	4 mm²
	Table 5-2	Circuit brea	ker recommended fo	or Grid connec	ction
	Model	5 kW	6 kW	8 kW	10 kW
Cicu brea	``  _ _	63 A	63 A	63 A	63 A
Table 5-3 Micro-breaker recommended for EPS connection					
	Model	5 kW	6 kW	8 kW	10 kW
Circu brea		63 A	63 A	63 A	63 A

# 6 Unpacking and Inspection

### 6.1 Unpacking

- The inverter undergoes 100% testing and inspection before delivery. However, damages may still occur during transportation. Before unpacking, please carefully check the external packaging for any signs of damage, such as punctures or cracks.
- Unpacking the inverter according to the following figure.




Figure 6-1 Unpacking the inverter (Australian version with cable protective cover)





Figure 6-2 Unpacking the inverter (European version without cable protective cover)


- Properly handle all the packaging materials in case they may be reused for storage and transportation of the inverter in the future.
- Upon opening the package, check whether the inverter is intact and whether all
  accessories are included. If any damage is found or any parts are missing, contact
  your dealer immediately.

## 6.2 Scope of Delivery
















































Table 6-1 Packing list

	Item	Quantity	Remark
/	Inverter	1 pc	
/	Wall mounting bracket	1 pc	
/	Cable protective cover	1 pc	For Australian version inverter only

	Item	Quantity	Remark
/	Positioning cardboard	1 pc	For locating the holes of the wall- mounting bracket For estimating the installation space
А	M5 screw	3 pcs for Australia 1 pc for Europe	For fixing the inverter For fixing the cable protective cover (Australia)
В	Positive PV connector	3 pcs for 5 kW and 6 kW; 4 pcs for 8 kW and 10 kW	
С	Positive PV pin contact	3 pcs for 5 kW and 6 kW; 4 pcs for 8 kW and 10 kW	
D	Negative PV connector	3 pcs for 5 kW and 6 kW; 4 pcs for 8 kW and 10 kW	
E	Negative PV pin contact	3 pcs for 5 kW and 6 kW; 4 pcs for 8 kW and 10 kW	
F	Positive PV dustproof buckle	3 pcs for 5 kW and 6 kW; 4 pcs for 8 kW and 10 kW	
G	Negative PV dustproof buckle	3 pcs for 5 kW and 6 kW; 4 pcs for 8 kW and 10 kW	
Н	Negative battery connector	2 pcs	
I	Positive battery connector	2 pcs	
J	Disassembling tool for PV terminal	1 pc	

	Item	Quantity	Remark
К	Communication signal connector	2 pcs	For Parallel and DRM connection
L	16 mm² R-type terminal	6 pcs	For Grid and EPS connection
М	4 mm² R-type terminal	2 pcs	For grounding
N	Self-tapping screw	3 pcs	For wall-mounting bracket installation
0	Expansion tube	3 pcs	For wall-mounting bracket installation
Р	Washer	3 pcs	For wall-mounting bracket installation
Q	RJ45 terminal	10 pcs	For COM, Parallel and DRM connection
R	RJ45 connector	1 pc	
S	Grid&EPS terminal waterproof cover	2 pcs	
Т	СТ	1 pc	
U	Document	/	
V	Dongle	1 pc	
W	Heat shrink tubing	1 pc	For Grid and EPS connection
Х	Manual changeover switch	1 pc	For whole home backup for Australia

#### NOTICE

• Refer to the actual delivery for the optional accessories.

## 7 Mechanical Installation

## **!** WARNING!

- Only qualified personnel are allowed to perform the mechanical installation in accordance with local laws and regulations.
- Check the existing power cables or other piping in the wall to prevent electric shock or other damage.
- Use insulated tools and wear personal protective equipment throughout the installation and maintenance process.

## **!** CAUTION!

• During installation, always be cautious about the weight of the inverter. Improper lifting or dropping of the inverter may result in personal injury.

#### NOTICE

• Install the inverter at a maximum back tilt of 5 degrees and avoid it being forward tilted, side tilted, or upside down.




Figure 7-1 Correct installation




Figure 7-2 Incorrect installation

## 7.1 Dimensions for mounting

Before installation, check the dimensions of the wall mounting bracket and ensure that enough space is reserved for the installation and heat dissipation of the entire system.




Figure 7-3 Dimensions (European version) (Unit: mm)




Figure 7-4 Dimensions (Australian version) (Unit: mm)

## 7.2 Installation procedures

Step 1: Horizontally align the positioning cardboard with the wall, plan the installation area of the inverter and the position of the holes of the wall-mounting bracket. The distance between the inverter terminals and the ground must be at least 60 cm, recommended distance is 140 cm. If cable protection cover needs to be installed, reserve a space of 16 cm below the existing outline of the positioning board when planning the installation area.




Figure 7-5 Planning the installation area

**Step 2:** Align the wall-mounting bracket with the wall, adjust the position of the bracket with a spirit level until the bubble stays in the middle, then mark holes.




Figure 7-6 Marking the holes

**Step 3:** Set the positioning cardboard and wall mounting bracket aside and drill holes with Ø10 drill bit. The depth of the holes should be 80 mm.




Figure 7-7 Drilling holes

**Step 4:** Take the expansion tubes (Part O) from the accessory bag, then knock them into the holes by rubber mallet.




Figure 7-8 Knocking the expansion tubes Fixing the wall-mounting bracket

**Step 5:** Attach the wall mounting bracket on the wall again. Insert the self-tapping screws (Part N) into the washer (Part P), fix the wall-mounting bracket to the wall, then tighten the screws with a Torque wrench.




Figure 7-9 Fixing the wall-mounting bracket

Step 6: Take out the inverter. If the inverter needs to be temporarily placed on the ground, use foam or other protective materials to protect it against potential damages. The bottom terminal should not come into contact with the ground or any other object that could cause damage to the terminal. Lift up the inverter collaboratively by the required number of personnel in accordance with the local regulation and hang it onto the wall mounting bracket. Make sure that the hanging holes of the inverter are properly inserted into the lugs of the bracket.




Figure 7-10 Hanging the inverter

**Step 7:** Use M5 screw (Part A) to secure the inverter with the wall-mounting bracket on the right side of the inverter.





Figure 7-11 Securing the inverter with the wall-mounting bracket

**Step 8:** (Optional) For safety reason, install an anti-theft lock. The anti-theft lock is not in the scope of delivery. If necessary, prepare a lock with a diameter less than ⊘10 mm by yourself, and keep the key to the lock in a safe place.



40

Figure 7-12 Locking the inverter

## 8 Electrical Connection

## /!\ DANGER!

• Before electrical connection, make sure the DC switch and AC breaker are disconnected. Otherwise, the high voltage may cause electric shock, resulting in severe personal injuries or even death.

## **!** WARNING!

- Only qualified personnel are allowed to perform the electrical connection following local laws and regulations.
- Strictly follow the instructions of this manual or other related documentation for electrical connection. Inverter damages caused by incorrect wiring are not covered by the warranty.
- Use insulated tools and wear personal protective equipment throughout the electrical connection process.

## 8.1 Overview of Electrical Connection

### 8.1.1 Terminals of Inverter




Figure 8-1 Terminals of Inverter

Table 8-1 Description of terminals

ltem	Description	Remarks	Decisive voltage class
А	DC switch		-
В	PV connection terminal	PV1, PV2 and PV3 terminals for 5 and 6 kW inverters; PV1, PV2, PV3 and PV4 terminals for 8 and 10 kW inverters	DVC-C
С	Battery/V2X connection terminal	(V2X: To be released)	DVC-C
D	Dongle terminal		DVC-A
E	Parallel connection terminal		-
F	DRM connection terminal		-
G	COM communication terminal	Including METER/CT, EVC/ RTU485, BMS1, BMS2, V2X and HEATPUMP.	DVC-A
Н	EPS connection terminal		DVC-C
I	Grid connection terminal		DVC-C
J	Ground connection point		-

### 8.1.2 Cable Connections of Inverter




Figure 8-2 Cable connections of inverter

Table 8-2 Dsecriptons of connected part

Item	Terminal	Part	Description	Source
Α	PV connection terminal	PV module	A PV string is composed of the PV modules connected in series. The number of input PV strings varies in accordance with different models.	Prepared by user
В	Battery/V2X connection terminal (V2X: To be released)	BAT & V2X	T-BAT-SYS-HV-S2.5/3.6; V2X can be connected with the series inverter.	Purchased from SolaX
С	Parallel connection terminal	X1-VAST series inverter	Select a same model of inverter	Purchased from SolaX

Item	Terminal	Part	Description	Source
D	Dongle terminal	Monitoring dongle, and USB for upgrading	Only SolaX monitoring dongle supported.	Purchased from SolaX
E	DRM connection terminal	Power grid scheduling device (only applicable to Australia and New Zealand)	Select the devices that meet the power grid scheduling requirements.	Prepared by user
F	V2X connection terminal	Dry contact controlled device/V2X	Generator and DC bidirectional EV-Charger are supported. For generator, select a generator equipped with an Auto Transformer Switch (ATS), and the rated output power of the generator should be greater than the sum of the load power and the battery charging power. (DC bidirectional EV-Charger: To be released)	Prepared by user
G	METER/CT communication connection terminal	Meter/CT	CT Supported meter: SolaX authorized DDSU666, DDSU666-CT, M1- 40, M3-40, M3-40-Dual, M3- 40-Wide.	Purchased from SolaX
Н	EVC/RTU485 communication connection terminal	SolaX communication device	SolaX DataHub and EV-Charger are supported. Select the device as needed.	Purchased from SolaX
I	HEATPUMP communication connection terminal	Adapter Box G2	Adapter Box G2 is supported. Select the device as needed.	Purchased from SolaX

Item	Terminal	Part	Description	Source
J	Grid/EPS connection terminal	AC switch	Select an appropriate AC switch according to the local regulations to ensure the inverter can be securely disconnected from the grid when an emergency occurs. Refer to "5.3 Additionally Required Materials" for the recommended specifications of AC switch.	Prepared by user

#### NOTICE

• For V2X connection availability, please check with the manufacturer / retailer for details.

Table 8-3 Descriptions of cables

Item	Cable	Type and specifications	Source
1	PV DC input power cable	Refer to "5.3 Additionally Required Materials".	Prepared by user
2	Battery power cable	/	Delivered with battery
3	Communication cable		
4	AC output cable	Refer to "5.3 Additionally Required Materials".	Prepared by user
5	PE cable		

#### 8.2 PE Connection

The inverter must be reliably grounded. The PE connection point has been marked with



( $\perp$ ) It is recommended to connect the inverter to a nearby grounding point.

### PE connection procedures

**Step 1:** Strip the insulation of the PE cable to an appropriate length.




Figure 8-3 Striping the PE cable

Step 2: Cut the length of heat shrink tubing as shown below. Pull the heat-shrink tubing over the PE cable and insert the stripped section into 4 mm<sup>2</sup> R-type terminal (Part M).




Figure 8-4 Installing the tubing and R-type teriminal

**Step 3:** Crimp it with crimping tool, pull the heat-shrink tubing over the stripped section of the R-type terminal and use a heat gun to shrink it so that it can be firmly contacted with the terminal.




Figure 8-5 Crimping the cable




Figure 8-6 Shrinking the tubing

**Step 4:** Remove the PE screw on the inverter with Allen key.




Figure 8-7 Uninstalling the screw

**Step 5:** Connect the assembled PE cable to the grounding point of the inverter, and secure it with the original screw. (Torque:  $3.0\pm0.1 \text{ N}\cdot\text{m}$ )




Figure 8-8 Securing the PE cable

Step 6: Connect the other end of the PE cable to the PE bar on the grid inlet wire.

#### NOTICE!

• You can choose one of the PE terminals to connect the PE cable.

### 8.3 AC Connection

#### NOTICE

 Before connecting the inverter to the grid, approval must be received by local utility as required by national and state interconnection regulations.

The inverter supports the EPS mode. When connected to the grid, the inverter outputs go through the Grid terminal, and when disconnected from the grid, the inverter outputs go through the EPS terminal.

### Requirements for AC connection

- Grid voltage requirement
  - » The grid voltage and frequency must be within the allowable range (220 V / 230 V, 240 V, 50 / 60 Hz) and comply with the requirements of the local power grid.
- Residual Current Device (RCD)
  - » The inverter does not require an external RCD when operating. If an external RCD is required by local regulations, a 300 mA Type-A RCD is recommended. If required by local regulations, a Type-B RCD is also permitted. Please refer to the actual regulatory requirements.
- AC breaker
  - An AC breaker that matches the power of the inverter must be used between the inverter output and the power grid. Each inverter must be equipped with an independent breaker or other load disconnection unit to ensure the safe disconnection from the grid. For specific information on the AC breaker for Grid and EPS, see "5.3 Additionally Required Materials".
- EPS load
  - » Make sure that the rated power of the EPS load is within the rated output power range of the inverter. Otherwise, the inverter will report an EPS Overload Fault alarm. In this case, turn off some loads to suit the rated EPS output power range of the inverter. After reporting the fault three times, press the ESC key on the LCD screen to clear the fault.
  - » When connecting to the EPS terminal, pay attention to the following points:

Medical equipment	Connection prohibited
Precision instrument	Connection prohibited
Appliances susceptible to malfunctions in the event of power outages during use.	Connection prohibited

» For inductive loads such as refrigerators, air conditioner, washing machine, etc., ensure that their start power does not exceed the EPS peak power of the inverter.

Table	8-4	EPS	load	infor	mation

Type of load	Equipment	Start power
	Lamp	Rated power
Resistive load	Fan	Rated power
	Hair dryer	Rated power
	Refrigerator	3-5 times rated power
Inductive load	Air conditioner	3-6 times rated power
muucuve toad	Washing machine	3-5 times rated power
	Microwave oven	3-5 times rated power

<sup>\*</sup> Refer to the nominal start power of the equipment for the actual start power.

### Wiring procedures

#### NOTICE!

- This section takes the wiring of the Grid terminal for example. It is also applicable to the wiring of the EPS terminal.
- For EPS terminal, you can select two-core or three-core copper wire according to grounded or not. It is recommended that the EPS terminal is grounded.

**Step 1:** Prepare a three-core cable as the Grid cable and strip the insulation of L, N and the grounding conductor to an appropriate length.




Figure 8-9 Stripping the Grid cable






Figure 8-10 Removing the dustproof cover

Step 3: Disassemble the Grid&EPS terminal waterproof cover (Part R) as shown below. There are two waterproof rings with different inner diameter. You can choose the suitable waterproof ring according to the cable diameter purchased by yourself. The applicable range is: H07RN-F 16 mm² standard cable outer diameter (Ø20.2 mm~Ø27.6 mm).




Figure 8-11 Disassembling the Grid&EPS terminal waterproof cover

**Step 4:** Thread the Grid cable through the swivel nut, waterproof ring and the connector enclosure in sequence.




Figure 8-12 Threading the grid cable

Step 5: Cut the length of heat shrink tubing (Part W) as shown below. Pull the heat-shrink tubing over the cable. Insert the conductors L, N, and the grounding conductor into the 16 mm² R-type terminals (Part L). Use the hydraulic crimping tool to crimp it. Make sure the conductors are correctly assigned and firmly seated in the R-type terminals. Pull the heat-shrink tubing over the stripped section of the R-type terminal and use a heat gun to shrink it so that it can be firmly contacted with the terminal.




Figure 8-13 Crimping the conductors




Figure 8-14 Shrinking the tubing

Step 6: Insert the crimped conductors L, N, and the grounding conductor into the terminal block according to the labeling and tighten the terminal block screws with Phillips head screwdriver: (torque:  $3.0 \pm 0.1 \text{ N} \cdot \text{m}$ ).




Figure 8-15 Connecting the AC cable

Step 7: Fasten the metal cover on the connector enclosure into the terminal body, tighten the metal cover screw (0.5 $\pm$  0.1 N·m) using a flat-head screwdriver, then lock the swivel nut.




Figure 8-16 Installing the AC connector to inverter

### **!** DANGER!

 Before powering on the inverter, make sure the Grid and EPS connectors have been installed correctly on the Grid and EPS terminal even if the EPS terminal is not wired. Otherwise, electrical shock may be caused by high voltage, resulting in serious personal injury or death.

### 8.4 PV Connection

## ♠ DANGER!

- When exposed to the sunlight, PV modules will generate lethal high voltage. Please take precautions.
- Before connecting the PV modules, make sure that both DC switch and AC breaker are disconnected, and that the PV module output is securely isolated from the ground.

## **!** WARNING!

• To mitigate the risk of fire, it is crucial to utilize a dedicated crimping tool specifically designed for PV installations to ensure secure and reliable connections.

## / CAUTION!

• Power is fed from more than one source and more than one live circuit.

### Requirements for PV connection

- Open circuit voltage and operating voltage
  - The open circuit voltage of each module array cannot exceed the maximum PV input voltage (600 V) of the inverter. Otherwise, the inverter may be damaged.
  - The operating voltage of PV modules must be within the MPPT voltage range (40-560 V) of the inverter. When the open circuit voltage exceeds 570V, the inverter will prompt a PV Volt Fault alarm. Consider the impact of low temperature on the voltage of the photovoltaic panels, as lower temperatures tend to result in higher voltages.
- PV module
  - » The PV modules within the same MPPT channel are of the same brand. Additionally, the strings within the same channel should have identical quantities, and be aligned and tilted identically.
  - » The positive or negative pole of the PV modules should not be grounded.
  - » The positive cables of the PV modules must be connected with positive DC connectors.
  - » The negative cables of the PV modules must be connected with negative DC connectors

### Wiring procedures

**Step 1:** Strip the insulation of the PV cables to an appropriate length.




Figure 8-17 Stripping the PV cable

**Step 2:** Insert the stripped cable into the PV pin contact (Part C&E). Make sure the PV cable and PV pin contact are of the same polarity.




Figure 8-18 Inserting the PV pin contact

**Step 3:** Crimp it with crimping tool for PV terminal. Pay attention to the crimping position.




Figure 8-19 Crimping the terminal

**Step 4:** Thread the PV cable through swivel nut and insert the cable into the Positive & Negative PV connector (Part B&D).




Figure 8-20 Threading the PV cable

**Step 5:** A "Click" will be heard if it is connected correctly. Gently pull the cable backward to ensure firm connection. Tighten the swivel nut. Verify that the PV connectors have the correct polarity before connection.




Figure 8-21 Securing the PV cable

**Step 6:** Use a voltage measuing device which complies with the local regulation to measure the positive and negative voltage of the assembled PV connectors. Make sure the open circuit voltage does not exceed the input limit of 600 V.




Figure 8-22 Measuring the voltage of PV connectors

#### NOTICE

If the voltage reading is negative, it indicates an incorrect DC input polarity.
 Please check if the wiring connections on the measuring device are correct or PV connectors are not mistakenly connected.

Step 7: Remove the PV terminal caps and connect the assembled PV connectors to the corresponding terminals until there is an audible "Click". The PV+ on the string side must be connected to the PV+ on the inverter side, and the PV- on the string side must be connected to the PV- on the inverter side.




Figure 8-23 Connecting the PV cable

**Step 8:** Seal the unused PV terminals with the dustproof buckles (Part F&G).




Figure 8-24 Covering the dustproof buckles

## **!** WARNING!

• Seal the unused PV terminals with the dustproof buckles. If all PV terminals are connected, keep the dustproof buckles in a safe place. Reinstall them immediately after removing the connectors from the terminals.

## 8.5 Battery/V2X Power Cable Connection

## / DANGER!

- Before connecting the cables, make sure the breaker, power button (if any) and DC switch (if any) of battery is OFF.
- Always ensure correct polarity. Never reverse the polarity of the battery cables as this will result in inverter damage.

#### NOTICE!

• The power cable of battery is in the battery accessory pack. NOT in the scope of inverter's delivery.

### Requirments for battery connection

- Battery
  - » SolaX Lithium-ion battery
  - The inverter is equipped with two independent battery terminals, allowing for connection to two separate battery strings. If two string batteries are connected to the two battery ports separately, the maximum charge / discharge current of each battery is 25A; if one string battery is connected to only one battery port, the maximum maximum charge / discharge current is 30A.
  - » Make sure the input voltage of each BAT terminal is higher than minimum voltage 80 V and lower than maximum input voltage 480 V.
- Micro circuit breaker (MCB)
  - » If the battery is integrated with a readily accessible internal DC breaker, no additional DC breaker is required. If local regulations mandate the use of a DC MCB between the battery and the inverter, install a non-polar DC MCB.
  - » The nominal voltage of DC MCB should be larger than maximum voltage of battery.
  - » For requirements on the current of MCB, see the related documentation. For T-BAT-SYS-HV-S2.5/3.6, the maximum current is 45A and 50A.
- Battery configuration information

Model	T-BAT-SYS-HV-5.8	T-BAT-SYS-HV-3.0	T-BAT-SYS-HV-S2.5 T-BAT-SYS-HV-S3.6 T-BAT-SYS-HV-S51
Total	1~6	1~8	2~16
Single battery port	1~3	1~4	2~8

### Wiring procedures

**Step 1:** Strip the insulation of the battery power cable to an appropriate length.




Figure 8-25 Stripping the battery cable

**Step 2:** Insert the stripped cable into the battery pin contact. Make sure that the stripped cable and the battery pin contact are of the same polarity.




Figure 8-26 Inserting the battery pin contact

**Step 3:** Fasten the buckle into the slot, you can hear a click sound, then push the ends together, and tighten the swivel nut.




Figure 8-27 Diagram of buckle and slot




Figure 8-28 Fastening the buckle




Figure 8-29 Tightening the swivel nut

**Step 4:** Remove the battery terminal caps and connect the assembled battery connectors (Part H&I) to corresponding terminals until there is an audible "Click".




Figure 8-30 Connecting the battery connector




Keep the terminal caps in a safe place if batteries are connected to the inverter.
 Reinstall the caps immediately after removing the connectors from the terminals.

### 8.6 COM Communication Connection

### 8.6.1 Pin Assignment of COM Terminal

The COM terminal is used for Meter or CT connection via METER/CT communication terminal; SolaX internal device connection via EVC/RTU485; battery communication via BMS1 and BMS2 terminal; generator and DC bidirectional EV-Charger via V2X terminal.



### 8.6.2 Meter/CT Connection

The inverter should work with an electric meter or current transformer (CT for short) to monitor household electricity usage. The electricity meter or CT can transmit the relevant electricity data to the inverter or platform.

## **!** CAUTION!

 The inverter will prompt a Meter Fault alarm if meter is selected in the LCD screen but not connected to inverter. Smart meters must be authorized by our company. Unauthorized meter may be incompatible with the inverter, thereby resulting in inverter damage and working mode malfunction. SolaX will not be responsible for the impact caused by the use of other appliances.

#### NOTICE

- Do not place the CT on the N wire or ground wire.
- Do not put CT on the N wire and L wire at the same time.
- Do not place the CT on the side where the arrow points to the inverter.
- Do not place the CT on non-insulated wires.
- The cable length between CT and inverter should not exceed 100 meters.
- It is recommended to wrap the CT clip around in circles with insulating tape.

### Meter/CT pin assignment

Pin	Pin assignment	Description	
1	CT1_1	For CT1 connection	
2	/		
3	CT2_1	For CT2 connection	
4	METER_485A	— For Meter connection	
5	METER_485B		
6	CT2_1	For CT2 connection	
7	/		
8	CT1_2	For CT1 connection	

### Meter/CT wiring procedure

**Step 1:** Thread the communication cable through the COM connector. (You can also crimp the RJ45 terminals first, then thread the cable through the COM connector)




Figure 8-31 Threading the communication cable

**Step 2:** Strip and crimp the communication cable.

- » For CT connection
  - a. Strip around 15 mm wire insulation off both ends of the cable.




Figure 8-32 Stripping the communication cable for CT

b. Insert the conductors at both ends respectively to terminal A and another RJ45 terminal (Terminal B) based on the pin definition of the inverter CT/ Meter port, and then use a crimping tool to crimp both cable ends.




Figure 8-33 Crimping the communication cable for CT

Table 8-5 Pin number and color

1 2	3 .	4 5 6	7 8
		Ź	
4		4	1
Ш	M.	И	И

PIN No.	Color	PIN No.	Color
1	Orange-White	5	Blue-White
2	Orange	6	Green
3	Green-White	7	Brown-White
4	Blue	8	Brown

- » For meter connection
  - a. Strip around 15 mm wire insulation off one end of the communication cable.




Figure 8-34 Stripping the communication cable for meter

b. Insert the conductors respectively into pin 4 and pin 5 of the RJ45 terminal, and then use a crimping tool to crimp them.




Figure 8-35 Crimping the communication cable for meter

**Step 3:** Insert the RJ45 terminal into the CT/Meter port, and then secure the waterproof connector. An audible "Click" will be heard if it is successfully connected.




Figure 8-36 Connecting cable to the Meter/CT port

# 8.6.3 EVC/RTU485 Communication Connection

The inverter supports communication with EV-Charger, DataHub etc via EVC/RTU485 terminal. Please refer to "15.3 Application of EV-Charger" and "15.4 Application of DataHub" for the specific application of EV-Charger and DataHub.

# 8.6.4 BMS Communication Connection

Through BMS1 and BMS2 communication terminal, the inverter can be connected to two independent batteries of different capacities. The model of each battery string must be the same.

# BMS connection diagram




Figure 8-37 BMS connection diagram

# 8.6.5 V2X Communication Connection

V2X terminal is designed to support generator and DC bidirectional EV-Charger connection through dry contact.

For generator, please refer to "15.1 Application of Generator" for specific application.

# V2X pin assignment

Table 8-6 V2X pin assignment

Pin	Pin assignment	Description
1	DI_A	,
2	DI_B	
3	DO2_A	/
4	V2X_CANH	DC Didirectional EV Charger
5	V2X_CANL	DC Bidirectional EV-Charger
6	DO2_B	/
7	DO_A	gonorator
8	DO_B	generator

### 8.6.6 HEATPUMP Communication Connection

The inverter supports communication with HEATPUMP via HEATPUMP terminal. Please refer to "15.2 Application of Adapter Box G2" for the specific application of HEATPUMP.

# 8.6.7 COM communication connection wiring procedure

**Step 1:** Loosen the securing screw on COM connector, and then hold the latches on both sides of the connector to pull it out from the enclosure.




Figure 8-38 Removing the connector enclosure

**Step 2:** Loosen the swivel nut on the enclosure, and then remove the sealing plugs from the cable support sleeve as needed. Remove the sealing plugs according to actual useage.




Figure 8-39 Disassembling the connector

# Step 3: Thread the network cables

Method one: Thread the network cables with RJ45 connectors. Directly thread
the cable through the swivel nut and connector enclosure in sequence. (Do not
thread the cable through the cable support sleeve at this time.)




Figure 8-40 Threading the cables with RJ45 terminals

- Method two: Thread the network cables without RJ45 terminals.
- a. Thread the cables without RJ45 terminals through the swivel nut and connector enclosure in sequence and then strip the insulation of these cables to an appropriate length. (Do not thread the cable through the cable support sleeve at this time.)




Figure 8-41 Threading the cables and stripping the insulation

b. Insert the stripped section into the RJ45 terminals. Crimp it tightly with a crimping tool for RJ45. Pay attention to the pin order of RJ45 terminals. Use a network cable tester to check if the cable has been correctly and properly crimped before connecting to inverter.




Figure 8-42 Crimping the communication cable

**Step 4:** Install the network cables of the crimped RJ45 terminals (Part Q) to METER/CT, EVC/RTU485, BMS1, BMS2, V2X and HEATPUMP cable terminals according to the labeling.




Figure 8-43 Installing the network cable to the cable terminal

- **Step 5:** Secure the assembled connector on COM terminal.
  - a. Install the connector enclosure back into the COM terminal.
  - b. Install the cable support sleeve into the enclosure.
  - c. Tighten M3 screw to secure it. (Torque:  $0.6 \pm 0.1 \text{ N} \cdot \text{m}$ )
  - d. Tighten the swivel nut to finish the COM wiring connection.




Figure 8-44 Securing the connector




Figure 8-45 Connector connected

# 8.7 PARALLEL and DRM Communication Connection

# 8.7.1 Pin Assignment of PARALLEL and DRM Terminal

PARALLEL terminal is used for inverter parallel, DRM terminal is used to control the inverter to response.




Table 8-7 Pin assignment of PARALLEL and DRM terminal

Pin assignment
Parallel_485A
Parallel_485B
1
Parallel_CANH
Parallel_CANL
GND_COM
Parallel_SYN1
Parallel_SYN2
DRM1/5
DRM2/6
DRM3/7
DRM4/8
+3.3V
COM/DRM0

Pin	Pin assignment
7	GND_COM
8	GND_COM

#### 8.7.2 Parallel Connection

The inverter provides the parallel connection function. One inverter will be set as the **Master** inverter to control the other **Slave** inverter in the system. For details, please refer to "15.6 Application of Parallel Function".

### 8.7.3 DRM Connection (Applicable to AS/NZS 4777.2)

According to AS/NZS 4777.2, the inverter needs to support the function of demand response mode (DRM). With the use of an external control box, active or reactive power regulation can be realized in a timely and fast manner, and the inverter can be operated stably during the process of regulation.

DRM 0, DRM 1 and DRM 5 are available now.




Figure 8-46 DRED connection diagram

Table 8-8 Desciptions of DRM

Mode	Pin	Requirement
DRM 0	Pin 6	<ul><li>When S0 is turned on, the inverters shut down.</li><li>When S0 is turned off, the inverters restore grid connection.</li></ul>
DRM 1	Pin 1	When S1 is turned on, the inverters do not input active power.
DRM 5	Pin 1	When S5 is turned on, the inverters do not output active power.

To enhance safety and reduce the risk of injury, you can install the shut down switch in a readily accessible location through DRM connection. In the event of an emergency, the shut down switch can be easily reached and pressed to promptly switch off the entire system, ensuring a swift response and preventing further harm.

# Shut down switch connection diagram




Figure 8-47 Shut down switch connection diagram

When shut down switch is pressed, the system will be powered off. To release the switch, press it again.

# 8.7.4 PARALLEL and DRM communication connection wiring procedure

**Step 1:** Loosen the waterproof caps of the PARALLEL and DRM terminals. You can remove or keep the waterproof cap. It is recommended to keep the waterproof cap, you can reinstall it if you choose not to connect the cable.




Figure 8-48 Loosening the waterproof cap

**Step 2:** Loosen the swivel nut of the communication signal connector (Part K), then remove the cable support sleeve.




Figure 8-49 Disassembling the connector

# **Step 3:** Thread the network cables

Method one: Thread the network cables with RJ45 connectors. Directly thread
the cable through the swivel nut, cable support sleeve and connector enclosure
in sequence.




Figure 8-50 Threading the cables with RJ45 terminals

- Method two: Thread the network cables without RJ45 terminals.
- a. Thread the cables without RJ45 terminals through the swivel nut, cable support sleeve, and connector enclosure in sequence and then strip the insulation of these cables to an appropriate length.




Figure 8-51 Threading the cables and stripping the insulation

b. Insert the stripped section into the RJ45 terminals. Crimp it tightly with a crimping tool for RJ45. Pay attention to the pin order of RJ45 terminals. Use a network cable tester to check if the cable has been correctly and properly crimped before connecting to inverter.




Figure 8-52 Crimping the communication cable

- **Step 4:** Secure the assembled PARALLEL and DRM connector on PARALLEL and DRM terminals.
  - a. Install the connector enclosure back into the PARALLEL and DRM terminals.
  - b. Install the cable support sleeve into the enclosure.
  - c. Tighten the swivel nut to finish the PARALLEL and DRM wiring connection.




Figure 8-53 Securing the connector




Figure 8-54 Connector connected

# 8.8 Monitoring Connection

The inverter provides a Dongle terminal, which can transmit data of the inverter to the monitoring website via WiFi+LAN dongle. The WiFi+LAN dongle is equipped with two kinds of communication modes (Wi-Fi mode or LAN mode). Users can choose based on actual needs. (If needed, purchase products from us.)

# Monitoring connection diagram




Figure 8-55 Wi-Fi mode connection diagram




Figure 8-56 LAN mode connection diagram

# Monitoring wiring procedure

#### Wi-Fi mode:

a. Assemble the dongle (Part V).




Figure 8-57 Assembling the dongle

b. Plug the dongle to the inverter.




Figure 8-58 Dongle connection procedure

# ( CAUTION!

• The buckles on the inverter and dongle must be on the same side. Otherwise, the dongle may be damaged.

#### NOTICE!

- The distance between the router and the inverter must be no more than 100 meters. If there are walls in between, the distance must be no more than 20 meters.
- For locations where Wi-Fi signals are weak, install a Wi-Fi signal booster.

#### NOTICE

• For details on Wi-Fi configuration, see *Pocket WiFi + LAN Installation Manual.* You can configure Wi-Fi only after the inverter is powered on.

### LAN mode:

a. Disassemble the waterproof connector into components 1, 2, 3 and 4; Component 1 is not used. Keep it in a safe place.




Figure 8-59 Disassembling the waterproof connector

b. Assemble the dongle.




Figure 8-60 Assembling the dongle

c. Plug the dongle to the inverter.

# 8.9 Cable protective cover installation (Australian version only)

After the mechanical installation and all electrical connections have been completed, you can install the cable protective cover.

**Step 1:** Take the cable protective cover out of the carton, rotate the support frame to open it, then remove the buffer material.




Figure 8-61 Opening the support frame




Figure 8-62 Removing the buffer material

**Step 2:** Rotate the support frame by 90 degrees, and lock into the protective mask. When you hear the click sound, it means that the buckle of support frame has been locked into the mask, and the cable protective cover is assembled.




Figure 8-63 Locking the protective mask




Figure 8-64 Locking the protective mask

**Step 3:** Push the cable protective cover vertically in the direction of the inverter port.




Figure 8-65 Pushing in the cable protective cover

**Step 4:** Press the Ø3.8 mm cylinder buckles on the cable protective cover into the corresponding holes on the inverter, make sure the cable protective cover hang on the inverter.




Figure 8-66 Right side cable protective cover installation




Figure 8-67 Left side cable protective cover installation

**Step 5:** Take the M5 screws (Part A) from the accessory bag, then tighten the M5 screws.




Figure 8-68 Left side cable protective cover installation




Figure 8-69 Right side cable protective cover installation

# 9 System Commissioning

# 9.1 Checking before Power-on

No.	ltem	Checking details	
1	Installation	The inverter is installed correctly and securely. The battery is installed correctly and securely. Other device (if any) is installed correctly and securely.	
2	Wiring	All DC, AC cables and communication cables are connected correctly and securely; The meter/CT is connected correctly and securely. The ground cable is connected correctly and securely;	
3	Breaker	All the DC breakers and AC breakers are OFF;	
4	Connector	The external AC and DC connectors are connected; The connectors on the Grid and EPS terminal are connected correctly and securely.	
5	Unused terminal	Unused terminals and ports are locked by waterproof caps. Unused PV terminals are locked by dustproof buckles.	
6	Screw	All the screws are tightened.	

# 9.2 Powering on the System

- **Step 1:** Turn on the DC switch and check the LCD screen.
  - » If the LCD screen is not on, turn off the DC switch and check whether the PV polarity is connected correctly.
  - » If the error of any channel of PV is displayed on LCD, turn off the DC switch and check the corresponding channel of PV connection.
- Step 2: Set Safety Code according to different countries and grid-tied standards on the LCD screen. The inverter cannot be connected to the grid before the safety code is correctly set.
- **Step 3:** Set the **System ON/OFF** to ON state on the LCD screen.

- **Step 4:** Switch on the AC breaker and wait for the inverter to power on. After powering on the inverter, you can check whether Meter/CT is correctly connected.
  - » If CT is connected, please perform the **Meter/CT Check** on the LCD screen to check the correct connection
  - » If meter is connected, please set the connection of meter through **Meter/ CT Settings** and perform the **Meter/CT Check** on the LCD screen.
  - » If Meter/CT is successfully connected, the power information of Meter/CT will be displayed on the LCD screen. If the Meter/CT connection fails, the screen will prompt "Meter Fault" or "Missed CT Fault".
- **Step 5:** Switch on the battery or the breaker, button, DC switch of the battery (see documentation of the battery manufacturer).
- Step 6: Check the LCD screen and perform Forced Discharge and Forced Charge through the setting path Menu>Work Mode>Manual to verify if the charging and dischaging of battery is normal.

# 9.3 Commissioning of inverter

» To select Australia Region A/B/C for grid protection settings:

Settings > Advance Settings > On-grid Settings > Safety Code

» To set power quality response modes settings Q(u):

Settings > Advance Settings > On-grid Settings > Power Factor

» To adjust grid protection settings:

Settings > Advance Settings > On-grid Settings > Grid Parameters

# 9.4 Checking after the commissioning of inverter

» To check Grid Code/ Region settings:

Settings > Advance Settings > On-grid Settings > Safety Code

» To check power quality response modes settings Q(u):

Settings > Advance Settings > On-grid Settings > Power Factor

» To check grid protection settings:

Settings > Advance Settings > On-grid Settings > Grid Parameters

» To check inverter firmware version:

About > Inverter

# 10 Operation on LCD

### 10.1 Introduction of Control Panel




Figure 10-1 Control Panel


- In a normal state, the **Power**, **Today** and **Battery** information will be displayed. You can press the keys to switch information.
- In an error state, the fault message and error code will be displayed, please refer to "12.2 Troubleshooting" for corresponding solutions.

LED indicator Status Definition Light on The inverter is in a normal state. The inverter is in a waiting or checking Operating Blinking state. Light on The inverter is in a fault state. Error One of the battery terminal is Light on connected in a normal state at least One of or both of the battery terminals Battery Blinking are connected and in an idle state.

Table 10-1 Definition of indicators


	Solid displa	One of the battery terminals is connected normally at least.	
	<b>B</b> linking	Both of the battery terminals are disconnected or connected abnormally.	
	Table 10-2 Def	inition of keys	
Кеу	Definition		
<b>S</b> ESC key	Exit from the current interface or function		
<b>S</b> Up key	Move the cursor to the upper part or increase the value		
<b>S</b> Down key	Move the cursor to the lower part or decrease the value		
Enter key	Confirm the selection		

# 10.2 Introduction of Menu Interface




There are seven submenus in the menu that can be selected for relevant setting operations.

- System ON/OFF: Switch on and off the inverter.
- Work Mode: Select the working mode of the inverter, including Self Use Mode, Feed-in Priority, Backup Mode, Peaking Shaving, TOU and Manual.




• System Status: Display the real-time value of PV, battery, etc. Including MPPT, Battery 1, Battery 2, On-grid, EPS, Meter/CT and COMM Status.




- Parallel Status: Display all the status data from master inverter when the inverters are parallel-connected.
- History Data: Display the history data of On-grid, EPS, Meter/CT\_1, Meter/CT\_2 and Error Log.




 Setting: Set the parameters of the inverter, including User Setting and Advance Setting.





About: Display the information about Inverter, Battery 1, Battery 2 and Internal code.



# 10.3 System ON/OFF

Setting path: Menu>System ON/OFF

Select **ON** or **OFF** to switch on and off the inverter. The interface is displayed **OFF** by default. When you select **ON**, the inverter stars running and display **System ON**.



### 10.4 Work Mode

Selecting path: Menu> Work Mode

Here you can only select the working mode. Six working modes are available for you to choose in on-grid status, i.e Self Use mode, Feed-in Priority, Backup mode, Peak shaving, TOU mode and Manual. You can choose the working modes according to your lifestyle and environment. Please refer to "2.7 Working Mode" for introduction of the modes and "10.7.1 User Setting" for specific setting of each mode.

=====Mode Select===== >Self Use Feed-in Priority Backup Mode

After entering into the Work Mode interface, you can set **Self Use**, **Feed-in Priority**, **Backup Mode**, **Manual**, **Peak shaving** and **TOU** as follows:

» Selecting Self Use

**Feed-in Priority, Backup Mode, Peak Shaving and Manual** have the same setting logic as Self Use.



» Selecting TOU

TOU can only be set in SolaX Cloud App. Aftering setting the TOU in the App, the selected TOU mode will be displayed in TOU interface on the LCD.

Min SoC: The minimum SoC of the system.

Min Soc: Default: 10%

==Work Mode== Work Mode: > TOU < Press Ent to save ==TOU== Min Soc: 10% Self Use: Same working logic with "Self Use Mode", but it is not limited by the charging and discharging time slots. The priority of PV: Loads > Battery > Grid.

Min Soc: Default: 10%



**Battery off:** The battery neither charges nor discharges. The power of PV will supply to loads or the grid. Only when the battery SOC is lower than the system (TOU) **Min SOC**, the battery can be charged.



**Peak shaving**: The working logic is that when the power consumption from the grid exceeds the set PeakLimit value, the battery is allowed to discharge power. The excess power beyond the limit is provided by the combination of photovoltaic and battery to ensure that the maximum power purchased from the grid does not exceed the set limit.

Peaklimits: Default: 1000W



Charging: The power of PV will charge the battery as much as possible to the set SOC of Charge BAT to (%). You can set whether to Charge from grid. The default value of Charge BAT to (%) is 100%. When the battery reaches the set SOC, the surplus power will perform "Self Use Mode" or supply to the grid ( based on the system setup), at this point, Charge from grid is not allowed.

Charge from grid: Default: Disable

Charge BAT to: Default: 50%; range:10%~100%

==TOU== Current Mode: Charging

==Charging== Charge from grid: Disable ==Charging== Charge BAT to: 100% Discharging: If allowed by the battery, the system outputs a specified power from the grid based on the set output percentage, controlling the power at the AC port. You need to set the RatePower (%) through Web or App when choosing Discharging mode. When the battery Discharge to (%) reaches the set SOC, the inverter performs "Self-use Mode".

Rate of AC Power: Default: 100%; range:0%~100%

Discharge to: Default: 10%; range:10%~100%



# 10.5 System Status

Displaying path: Menu>System Status

After entering into the **System Status** interface, the status of MPPT, Battery1, Battery2, Ongrid, EPS, Meter/CT and COMM Status will be displayed on the LCD as follows:


PV status: You can see information of MPPT1, MPPT2, MPPT3 and MPPT4.
 Information contains input voltage, current and power of each PV. The value in MPPT4 is only available for 8kW and 10 kW inverters.



Battery status: There will be information of Battery1 and Battery2 displayed here.
It shows the status of each battery terminal, including the voltage, current, power,
SOC, cell temperature and BMS connection status. Positive value with power
means charging; negative value means discharging.



 On-grid status: Information contains the voltage, current, output power and frequency of Grid terminal. Positive value with power means power output; negative value means power input.



 EPS status: Information contains apparent power, voltage, current, active power and frequency of EPS terminal when it is disconnected from the grid.



 Meter/CT status: Information contains feed-in power detected by the connected meter or CT. Positive value means power fed into grid; negative value means power taken from grid.



 COMM Status: Here you can set WiFi communication status, including inverter to Dongle / Router / Server, "On" means communication normal, "Off" means communication disconnection.



### 10.6 Parallel Status

Displaying path: Menu>Parallel Status

Here you can check the parallel status, the number of all inverters and slave inverter.




# 10.7 History Data

Displaying path: Menu>History Data

After entering the **History Data** interface, the status of **On-grid**, **EPS**, **Meter/CT\_1**, **Meter/CT\_2**, **Error Log** will be displayed on the LCD as follows:


- On-grid: A record of the output and input electric energy of the inverter today and the total (through Grid terminal).
  - » Output Today: Output electric energy of the inverter today.
  - » Output Total: Total output electric energy since the inverter activated for the first time.
  - » Input Today: Input electric energy of the inverter today.
  - » Input Total: Total input electric energy since the inverter activated for the first time.




• **EPS**: A record of the output electric energy of the inverter totay and the total, when it is disconnected from grid (through EPS terminal).



- Meter/CT\_1: The total electricity fed into or taken from the grid since the inverter activated for the first time and on that day (detected by Meter/CT).
  - » Feedin Today: Electricity sold to grid today.
  - » Feedin Total: Total electricity sold to grid since the inverter activated for the first time.
  - » Consume Today: Electricity bought from grid today.
  - » Consume Total: Total electricity bought from grid since the inverter activated for the first time.



 Meter/CT\_2: The output electricity of the connected on-grid inverter totay and the total (detected by Meter 2). This function is only available when meter 2 is connected.



**Error Log**: Display the recent six error messages. Information contains date and time error happened, error code and error description.



# 10.8 Setting

Settings includes User Settings and Advanced Settings.

#### 10.8.1 User Setting

Setting path: Menu>Setting ("0 0 0 0")>User Setting

#### NOTICE

The default password for **User Setting** is "0 0 0 0".

# Setting Date & Time

You can set the current date and time of the installation site.

The display format is "2024-06-16 14:00", in which the first four numbers represent the year (e.g.  $2000 \sim 2099$ ); the fifth and sixth numbers represent the month (e.g.  $01 \sim 12$ ); the seventh and the eighth numbers represent the date (e.g.  $01 \sim 31$ ). The remaining numbers represent the time.



#### **Setting Language**

This inverter provides multiple languages for customers to choose, such as English, Deutsch, francais, Polskie, Espanol, Português. The default language is English.



# Setting EPS Mute

When the inverter is running in EPS Mode, you can choose whether the buzzer is turned on or not.

- Select Yes, the buzzer mutes.
- Select NO, the buzzer will sound every 4 seconds when the battery SOC is > EPS
  min. SOC. When the battery SOC is equal to EPS min. SOC, the buzzer will sound
  with higher frequency at every 400 ms. This function is turned off by default.



### Setting Self Use Mode

Please refer to "2.7.1 Self-use Mode" for working logic of this mode.

- Min SOC: Default: 10%; range: 10%~100%
  - » The minimum SOC of the battery. The battery will not discharge power when the SOC of the battery reaches this value.



- Charge from grid:
  - You can set whether the power can be taken from the grid to charge the battery in the forced charing period. When **Charge from grid** is set to **Enable**, the grid power is allowed to charge the battery; when it is set to **Disable**, the grid power is not allowed to charge the battery.



- Charge battery to: Default: 10%; range: 10%~100%
  - » Set the target SOC to charge the battery from grid in the forced charging period (applicable only when the **Charge from grid** is enabled).
  - » You can set your own target value, i.e. during the forced charging period, the inverter will use both PV & grid power to charge the battery to the target value. If the PV power is still sufficient (enough for load and there is excess power), the inverter will continue to charge the battery.



# Setting Feed-in Priority

Please refer to "2.7.2 Feed-in Priority" for working logic of this mode.

- Min SOC: Default: 10%; range: 10%~100%
  - » The minimum SOC of the battery. The battery will not discharge power when the SOC of the battery reaches this value.



- Charge battery to: Default: 50%; range: 10%~100%
  - » Set the target SOC to charge the battery from grid in the forced charging period.
  - you can set your own target value, i.e. during the forced charging period, the inverter will use both PV & grid power to charge the battery SOC to the target SOC value, after the battery SOC meets the target value, if the PV power is still sufficient, the surplus power will be fed into the grid.



### Setting Backup Mode

Please refer to "2.7.3 Backup Mode" for working logic of this mode.

- Min SOC: Default: 30%; range: 30%~100%
  - » The minimum SOC of the battery The battery will not discharge power when the SOC of the battery reaches this value.



- Charge battery to: Default: 50%; range: 30%~100%
  - In this mode, the charge from grid function is turned on by default, and customers can set the target value by themselves, that is, during the forced charging period, the inverter will use both PV & grid power to charge the battery to the target value. If the PV power is still sufficient (enough for load and there is excess power), the inverter will continue to charge the battery.



# Setting Chg&Dischg Period

Here you can set the Forced Chg Period and Allowed Dischg Period.

If two charging and discharging periods are needed, enable the **Function Control** to activate the **Chg&Dischg Period2**.

- Chg&Dischg Period: You can set the charge and discharge time according to your own needs. The default time axis of the system is 24h.
  - » Forced Chg Period Start Time: Time to start charging; default: 00:00; range: 00:00~23:59
  - » Forced Chg Period End Time: Time to stop charging; default: 00:00; range: 00:00~23:59
  - » Allowed Dischg Period Start Time: Time allows to start discharging (The charging or discharging of the battery depends on the working mode.); default: 00:00; range: 00:00~23:59
  - » Allowed Dischg Period End Time: Time to stop discharging; default: 23:59; range: 00:00~23:59



 Chg&Dischg Period2: The second time axis is closed by default. If two charging and discharging periods are needed, turn on the charging and discharging period
 This period will hold the same setting logic as Chg&Dischg Period.



#### NOTICE!

- The charging and discharging period is only applicable for self-use mode, feed-in priority and backup mode.
- In the period not set as forced charging period and allowed dischariging period, the battery can be charged but can not discharge power.
- In the period simutaneously set as forced charging period and allowed discharging period, the battery will be charged forcely.

## Setting Peak shaving mode

Please refer to "2.7.4 Peak Shaving Mode" for working logic of this mode.

- DisChgPeriod1: To set ShavingStartTime, ShavingEndTime and PeakLimits.
   DisChgPeriod1 can be regarded as Peak shaving period. This period should be set to cover load peaks. Battery will be discharged to shave load peak until battery SOC drops to Min SOC (10% by default).
  - » PeakLimits1: Default: 0 W, range: 0-60000 W

Once the consumption (from the grid) reaches this value, the inverter will start shaving to keep the consumption lower than this value.

» ShavingStartTime: Default: 7:00; range: 00:00~23:59

The battery starts discharging to shave consumption from the set time.

» ShavingEndTime: Default: 15:00; range: 00:00~23:59

The battery stops discharging at the set time.



- DisChgPeriod2: Same working logic with DisChgPeriod1
  - » PeakLimits2: Default: 0 W, range: 0-60000 W
  - » ShavingStartTime: Default: 19:00; range: 00:00~23:59

The battery starts discharging to shave consumption from the set time.

» **ShavingEndTime**: Default: 23:00; range: 00:00~23:59

The battery stops discharging at the set time.

- ChargeFromGrid: It can be used in specific time period. This period allows
  the inverter to take energy from grid to charge battery in order to have
  enough backup for peak shaving. Please note that this period starts from
  ShavingEndTime2, end until ShavingStartTime1.
  - » Enable: Activate the function of ChargeFromGrid to allow the inverter taking grid energy to charge battery. The ChargePowerLimits and MAX\_SOC will be displayed only when ChargeFromGrid is enabled.
  - » ChargePowerLimits: Default: 8000 W; range: 0-8000 W

Settable target power taken from grid. Inverter will use this target power taken from grid to charge battery.

» MAX\_SOC: Default: 50%; range: 10%-100%

Inverter will take grid energy to charge battery until battery SOC reaches this value.



- Reserved\_SOC: Default: 50%; range: 10%-100%
  - It can be used in specific time period. In this period, the inverter does not allow taking grid energy to charge the battery. PV is the only way to charge the battery and PV will charge the battery first. Inverter will not supply power to loads until battery SOC is higher than the **Reverved\_SOC** in order to save enough energy for later shaving period.



## **Setting User Password**

The default password is "0 0 0 0". You can reset the password here.

## 10.8.2 Advanced Setting

Setting path: Menu>Setting>Advance Setting

#### NOTICE

 All the adjustable parameters including safety code, grid parameter, export control, etc. can be modified under the permissions of installer password. Unauthorized use of the installer password by unauthorized persons can lead to incorrect parameters being inputted, resulting in power generation loss or violation of local regulation. Get the installer password from the dealer and never open the password to unauthorzied person.

## **Setting Safety Code**

Setting path: Menu>Setting>Advance Setting>On-grid Settings

#### NOTICE!

- The inverter cannot be connected to the grid before the safety code is correctly set. If there is any doubt about your safety code where the inverter installed, please consult your dealer or SolaX service for details.
- The setup will vary from different saftey codes.

Here you can set safety code according to different countries and grid-tied standards. In addition, the inverter has an **User Defined** option which allows you to customize relevant parameters with a wider range.

There are several standards to choose from, please refer to the LCD screen on the inverter. (May be changed or added without notice)

### AS4777 Setting

Setting path: Menu>Setting>Advance Setting>On-grid Settings

The function of **AS4777 Setting** is only activated when the **Safety Code** is set to AS4777 and New Zealand, which is only applicable to Australia and New Zealand.

 Select and enter AS4777 Setting in Advance Settings interface. You will see Exprot Control (for active power output control) and General Control (for apparent power output control).

> ====AS4777 Setting==== >Export Control

b. Set the **Soft Limit** value and **Hard Limit** value for Export Control and General Control. The figure below will take the setup of Export Control as an example. **Soft/Hard Limit Value**: Default: 4999W; range: 0-15000W



#### NOTICE!


- Soft Limit: Control the output value to grid within the set Soft Limit Value.
- Hard Limit: If the actual output value reaches the set Hard Limit Value, the system
  will automatically disconnect from grid and prompt error message on the LCD.

## Setting Main Breaker Limit

Setting path: Menu>Setting>Advance Setting>On-grid Settings

Due to power limit, the current of Meter or CT must be abide by the utility's requirements. You can set the corresponding amperage according to the utility's requirements. Failure to set the current may cause a circuit breaker fault of main switchboard, thus affecting the charging and discharging of battery.

The default value is 100 A, range: 10-100 A




### **Setting Export Control**

Setting path: Menu>Setting>Advance Setting>On-grid Settings

This function allows the inverter to control the output power to the grid. The **User Value** set here must be less than the maximum value. If the user does not want to feed power to the grid, set **User Value** to "0".

User Value: Default: 60000W: range: 0-60000W



#### NOTICE!

Under Safety Code AS4777.2, Export Control is in the path of Advance Setting>
 AS4777 Setting. You can set the Soft Limit and Hard Limit of Export Control to
 control the power output to grid. Please refer to section "AS4777 Setting" for details.

## **Setting Power Limit**

Setting path: Menu>Setting>Advance Setting>On-grid Settings

Here you can set the rated output power by percentage.

The percentage of rated output power is used as the actual output power.

Proportion: Default: 1.00; range: 0.00-1.10

====Power Limit==== Proportion 1.00

## **Setting FRT Function**

Setting path: Menu>Setting>Advance Setting>On-grid Settings

When the **Safety Code** is selected, the information of FRT Function corresponding to the selected safety code will be automatically matched.

Here you can **Enable** or **Disable** the **FRT Function**, and set the parameters of **OVRT Point** and **UVRT Point** when this function is enabled.

Default: Disable

**OVRT Point**: Default: 266V; range: 230~288V **UVRT Point**: Default: 181V; range: 46~240V

=====FRT Function===== >Func Select > Enable < =====FRT Function===== >OVRT Point =====FRT Function===== >UVRT Point

## Setting Grid parameters

### Setting path: Menu>Setting>Advance Setting>On-grid Settings

The default value is the specified value under the current safety regulations. The contents will be displayed according to the requirements of local laws and regulations. Please refer to the actual contents displayed on the LCD screen on the inverter.

====Grid Parameters==== >Overvoltage\_L1 Undervoltage\_L1 OverFreq\_L1

## **Setting Power Factor**

## Setting path: Menu>Setting>Advance Setting>On-grid Settings

The default value is the specified value under the current safety regulations. The contents will be displayed according to the requirements of local laws and regulations. Please refer to local grid requirements.




Table 10-3 Items under Power Factor

Off	
Over Excited	PF Value
Under Excited	PF Value

	P1 PF
	P2 PF
	P3 PF
	P4 PF
	Power 1
Curve	Power 2
	Power 3
	Power 4
	PflockInPoint
	PflockOutPoint
	3Tua
	SetQuPower1
	SetQuPower2
	SetQuPower3
	SetQuPower4
	QuRespondV1
Q(u)	QuRespondV2
Q(u)	QuRespondV3
	QuRespondV4
	К
	3Tua
	QuDelayTimer
	QuLockEn
Fixed Q Power	Q Power

- Reactive power control, reactive power standard curve  $\cos \varphi = f(P)$ 
  - » For VDE ARN 4105, the curve  $\cos \phi = f(P)$  should refer to curve A. The set default value is shown in curve A.




Figure 10-2 Curve A

- \*) If the grid-connected power of the inverter  $\leq$  4.6 kW, the Power Factor is 0.95 at 1.0 power; if the grid-connected power of the inverter > 4.6 kW, the Power Factor is 0.90 at 1.0 power.
- » For TOR, the curve cos  $\phi$  = f(P) should be curve B. The set default value is shown in curve B.




Figure 10-3 Curve B

- \*) Depend on the required Q capacity
- » For CEI 0-21, the default value of PFLockInPoint is 1.05. When Vac > 1.05Vn, Pac > 0.2 Pn, curve cos  $\varphi$  = f(P) corresponds to curve C.




Figure 10-4 Curve C

Reactive power control, reactive power standard curve Q= f(V)




Figure 10-5 Curve Q= f(V)

Figure 10-6

## **Setting Pu Function**

Setting path: Menu>Setting>Advance Setting>On-grid Settings

(Applicable to specific countries, please refer to local grid requirements.)

The Pu function is a volt-watt response mode required by certain national standards such as AS/NZS 4777.2. This function can control the active power of the inverter according to the grid voltage. You can set **Response Voltage**, **3Tau**, **PuPower**.

The items in the **P(u) Function** interface will be adjusted in accordance with the local safetyrequirements and law regulations, casual modification is prohibited.



For AS/NZS 4777.2, the curve required for the volt-watt mode can be referred to the below curve.




Figure 10-7 Curve for P(u)


## **Setting Pgrid Bias**

Setting path: Menu>Setting>Advance Setting>On-grid Settings

This function is disabled by default.

When the inverter has no power output:

- a. Check the Meter/CT value in Menu>System Status>Meter/CT when the function is disabled.
- b. If the Meter/CT displayed in System Status is negative value, please select Grid for Pgrid Bias to discharge power to the mains. If the Meter/CT displayed in System Status is positive value, please select INV for Pgrid Bias to take power from the mains.




### Setting DRM function (Applicable to AS/NZS 4777.2)

Setting path: Menu>Setting>Advance Setting>On-grid Settings

The DRM Function is a demand response method required by the AS/NZS 4777.2 standard and is only applicable to Australia and New Zealand.

The function is enabled by default.




## OFPL\_Setting

### Setting path: Menu>Setting>Advance Setting>On-grid Settings

When the output frequency of an inverter exceeds the specified maximum value, the inverter will automatically lower the output frequency, to avoid damages to the device and occurrence of accidents.

OFPL (Over Frequency Power Limit) is lowering the output frequency of an inverter, to control the ouput power. The following are parameter related to OFPL. The setting items may vary with the local safety regulations and requirements. The displayed content is subject to the actual situations.




## UFPL\_Setting

### Setting path: Menu>Setting>Advance Setting>On-grid Settings

When the output frequency of an inverter is lower than the specified maximum value, the inverter will automatically improve the output frequency, to ensure constant output.

UFPL (Under Frequency Power Limit) is improving the output frequency of an inverter, to ensure the ouput power. The following are parameter related to UFPL. The setting items may vary with the local safety regulations and requirements. The displayed content is subject to the actual situations.



## **Setting Charger**

Setting path: Menu>Setting>Advance Setting>Battery Settings

The inverter is compatible with lithium-ion battery. You can set the charge  $\vartheta$  discharge parameters of battery.

If one string battery is connected to only one battery port, the LCD will display single battery control.

- Max Charge: Maximum charging current of battery. Default: 30A, range: 0-30A
- Max Discharge: Maximum discharging current of battery. Default: 30A, range: 0-30A
- Charger upper limit: Default: 100%, range: 0%-100%
  - » The maximum battery SOC when charging.



If two string batteries are connected to two battery ports separately, the LCD will display two battery control of **Battery1** and **Battery2**. Here is taken Battery1 as an example.

- Max Charge: Maximum charging current of battery. Default: 25A, range: 0-25A
- Max Discharge: Maximum discharging current of battery. Default: 25A, range: 0-25A
- Charger upper limit: Default: 100%, range: 0%-100%
  - » The maximum battery SOC when charging.



## **Setting Battery Heating**


### Setting path: Menu>Setting>Advance Setting>Battery Settings

This function is disabled by default and is only valid when the battery has the heating function. You can enable **Battery Heating** function to make the battery heated. And set the heating period.

a. Enable the Battery Heating function.



 Set the heating start time and end time for the battery. Two heating periods can be set.



#### NOTICE!

 If the ambient temperature is extremely low, turning on battery heating will consume a significant amount of electrical energy.

### **Setting BAT Expansion**

#### Setting path: Menu>Setting>Advance Setting>Battery Settings

This function allows for the extension of battery modules, such as adding a new battery module to an existing system. It is only applicable and functional in on-grid mode and cannot be used in EPS mode. In on-grid mode, enabling this function will make the inverter to charge or discharge the battery SOC to approximately 38%. This function will turn to **Disable** automatically after 48 hours this function enabled.

If one string battery is connected to only one battery port, the LCD will display single battery control.

```
===BAT Expansion===
Function Control
> Enable <
```

If two string batteries are connected to two battery ports separately, the LCD will display two battery control of **Battery1** and **Battery2**. Here is taken Battery1 as an example.


```
===Battery1===
Function Control
> Enable <
```

## **EPS Setting**

Setting path: Menu>Setting>Advance Setting

Select and enter EPS Setting interface and set Frequency, Min SOC, Min ESC SOC, Super-Backup and UPS Switch in EPS mode.

- Frequency: Default: 50 Hz. Output frequency of EPS
- Min SOC: Default: 10%, range: 10%-25%
  - » If the battery SOC is lower than the Min SOC, the inverter will prompt BatPowerLow and turn off if there is no PV input.
- Min ESC SoC: Default: 20%, range: 15%-100%
  - » In EPS mode, the minimum SOC required for re-entry EPS mode after BatPowerLow prompted. When the battery SOC reaches the Min ESC SOC through charging from PV, the inverter will automatically enter EPS mode from EPS Waiting mode.



- Super-Backup: Default: Disable
  - » When Super-Backup is enabled, if there is only PV and no battery is available, the inverter can also enter EPS mode when there is a loss of grid.
- UPS Switch: Default: Disable
  - » When UPS Switch is enabled, the switching time of on-grid and off-grid will be reduced by less than 10ms.



## **Parallel Setting**

If a parallel operation is required, you can set it with Parallel Setting.

**Status** shows whether the inverter is in parallel status. **Free** means the inverter is not in parallel. **Master** means the inverter has been set in parallel and has become the master inverter. **Slave** means the inverter has been set in parallel and has become the slave inverter.

**Setting** means you can set the inverter's status. There are two status to choose: Free and Master. Default: Free



- Resistance switch: Default: OFF/ON
  - » Enable the Resistance Switch of one inverter among the parallel inverters, and the parallel inverters can communicate normally.



## Setting ExternalGen

Setting path: Menu>Setting>Advance Setting>Peripheral Settings

You can select **ATS Control** or **Dry Contact** to control ExternalGen. ExternalGen is disable by default.

#### Setting ATS Control to control ExternalGen


 Select ExternalGen and enter the interface, the default Disable interface will be displayed. Enable this function, then press Enter to select ATS Control and enter the interface.



- b. After entering into the ATS Control interface, you can set MAX Charge, Charg Period and Allowed Disc Period, Charge from Gen as follows:
  - » Setting MAX Charge

MAX Charge means the maximum power of the generator charged to the battery.

Max Charge: Default: 3000W; range: 0~8000W



» Setting Charg Period and Allowed Disc Period

Charg Period Start/End Time: Default: 00:00; range: 00:00~23:59


Allowed Disc Period Start Time: Default: 00:00; range: 00:00~23:59

Allowed Disc Period End Time: Default: 23:59; range: 00:00~23:59

Chrg&DischrgPeriod2 has the same setting logic as Forced Charg Period and Allowed Disc Period.

Charg Period Start/End Time: Default: 00:00; range: 00:00~23:59

Allowed Disc Period Start/End Time: Default: 00:00; range: 00:00~23:59



» Setting Charge from Gen

Charge battery to can only be set after Charge from Gen is enabled.

Charge battery to: Default: 30%; range: 10%~100%



» Setting Gen Min Power: Default: 500W; range: 0~60000W



#### Setting Dry Contact to control ExternalGen

 Select ExternalGen and enter the interface, the default Disable interface will be displayed. Enable this function, then press Enter to select Dry Contact and enter the interface.



- b. After entering into the Dry Control interface, you can set MAX Charge, Start Gen Method, Max Run Time, Min Rest Time, Allow Work Time, Charge and Discharge Period (Refer to Setting ATS Control "Setting Forced Charg Period and Allowed Disc Period" for details), Charge from Gen (Refer to Setting ATS Control Setting Charge from Gen for details) as follows:
  - » Setting Max Charge

Max Charge: Default: 3000W; range: 0~8000W

====ExternalGen==== > MAX Charge: 3000W

» Setting Start Gen Method

**immediately**: When the grid is disconnected from the inverter and the ExternalGen is enabled, the generator will start immediately.

**reference SoC:** The generator will start or close according to the Switch on/off SoC.

Switch on SoC: Default: 20%; range: 10%~100% Switch off SoC: Default: 80%; range: 10%~100%

> ====ExternalGen==== >Start Gen Method: immediately
>
> ====ExternalGen==== >Switch on SoC:

> > 20%

====ExternalGen==== >Start Gen Method: reference SoC ====ExternalGen==== >Switch off SoC: 80%

» Setting Max. Run Time and Min. Rest Time

Max. Run Time means the maximum time that the generator can run at a single start, and when the single start time reaches the maximum running time, the generator will actively shutdown.

Default: 1000min; range: 1~60000min

Min. Rest Time means once the generator is turned on, the generator can be turned off only after the minimum running time is reached.

Default: 60min; range: 1~60000min

====ExternalGen==== >MaxRunTime: 1000min ====ExternalGen==== >MinRestTime: 60min » Setting Allow Work Time

**Start Time**: Default: 00:00; range: 00:00~23:59

Stop Time: Default: 23:59; range: 00:00~23:59

====ExternalGen==== Allow Work >start time 00:00 ====ExternalGen==== Allow Work >stop time 23:59

» Setting Gen Min Power: Default: 500W; range: 0~60000W



### **Setting Modbus**

Setting path: Menu>Setting>Advance Setting>Peripheral Settings

You can select the baud rate and set the address of the external communication protocol for communicating with external equipment.

Baud Rate: Default: 19200

Address: Default: 1; range: 1~255




## Setting Solax485

Setting path: Menu>Setting>Advance Setting>Peripheral Settings

You can communicate with other SolaX equipments, such EV-Charger, DataHub and Adapter Box G2 etc. through **Solax485**.

- a. Select and enter Solax485 interface;
- Select the equipment which needs to be connected and set the corresponding Baud Rate and Address. Take COM485 as an example.

Baud Rate: Default: 19200 Address: Default: 1; range: 1~255



#### NOTICE

 When two equipments need to be connected at the same time, the baud rate and address of the two equipments shall be set to the same.

## Whole Home Backup

Setting path: Menu>Setting>Advance Setting>Whole Home Backup

Here you can enable the Whole Home Backup, disable is by default.



## Setting MicroGrid

Setting path: Menu>Setting>Advance Setting

Here you can Enable the function of MicroGrid.

Default: Disable

=====MicroGrid===== Micro Grid >Disable<

## **Setting Global MPPT**

You can set the shadow tracking speed with four options, which are **Off, Low, Middle**, and **High**. This function is off by default. PV4 is available for 8kW and 10kW inverters.

- Off: Switch off the shadow tracking function.
- Low: Scan the shadow every four hours.
- Middle: Scan the shadow every three hours.
- **High**: Scan the shadow per hour.



## HotStandby Settting

This function is mainly to reduce the energy losses of the system when the power of load is very low.

- Enable: When the power of load is very low and other conditions for entering
  hot standby are met, the inverter will enter HotStandby status to reduce system
  losses.
- Disabled: Even when the power of load is very low and other conditions for
  entering hot standby are met, the inverter will not enter HotStandby status and
  continue to output power to the load. It is disabled by default.

===HotStandby Setting=== Function Control > Enable <

## Setting ShutDown

ShutDown is an Enable Switch, it determins whether to allow the external switch to turn on and off the inverter. If you want to use the external switch, you can **Enable** this function.

Default: Disable

=====ShutDown===== ShutDown: >Disable<

## Setting Self Test (only for CEI 0-21)

The self test function allows users to test the following items: All Test, Ovp (59.S2) test. Uvp (27.S1) test, Uvp (27.S2) test, Ofp (81 > .S1) test, Ufp (81 < .S1) test, Ufp2 (81 > .S2) test, Ufp2 (81 < .S2) test, Ovp10 (59.S1) test.

In the **Self Test** interface, the user can select **All Test** or a single test item for testing. All tests take about 6 minutes. For a single test item, it takes about a few seconds or minutes.

Click **Test Report** to view the test results of all items.

Before testing, make sure that the inverter is connected to the grid.

## **Setting Reset**

Here you can reset value of Error Log, Meter/CT, INV Energy and Wifi; and restore to the factory set.

Reset Error Log



Reset Meter/CT 1



(For Reset Meter/CT\_1 Software, it is displayed only when SolaX meter is detected.)

Reset Meter/CT\_2



(For Reset Meter/CT\_2 Software, it is displayed only when SolaX meter is detected.)

Reset INV Energy



Reset Wifi



Factory Reset



### **Advanced Password**

You can reset the advanced password here.

## 10.9 About

Displaying path: Menu > About

Here shows the basic information of the inverter, battery and internal code. After entering the **About** interface, you can check those information.

- Inverter
  - » Inverter SN, Register SN, ARM Verion, DSP version, On-grid Runtime, EPS Runtime
- Battery1 and Battery2
  - BatBrand, Bat\_M SN (SN of BMS), Bat\_PS1 SN (SN of battery module 1), Bat\_PS2 SN (SN of battery module 2), Bat\_PS3 SN (SN of battery module 3), Bat\_PS4 SN (SN of battery module 4), Battery M Version (software version of BMS) and Battery S version (software version of battery module).
- Internal Code
  - » Internal code of inverter, battery1 and battery2
- Meter\_1 Info (It is displayed only when SolaX meter is detected.)
  - » Meter Type, SN, Software, Hardware
- Meter\_2 Info (It is displayed only when SolaX meter is detected.)
  - » Meter Type, SN, Software, Hardware

# 11 Operation on SolaX App and Web

## 11.1 Introduction of SolaXCloud

SolaxCloud is an intelligent management platform for home energy, which integrates energy efficiency monitoring, device management, data security communication and other integrated capabilities. While managing your home energy device, it helps you optimize the efficiency of electricity consumption and improve the revenue of power generation.

## 11.2 Operation Guide on SolaXCloud App

## 11.2.1 Downloading and Installing App

Method 1: Select and scan the QR code below to download the app.

The QR codes are also available on the lower-right corner of the login page of our official website (www.solaxcloud.com), and the manual of the dongle.



Figure 11-1 QR code

Method 2: Search for **SolaXCloud** in Apple Store APP or Google Play Store, and then download the app.

## 11.2.2 Operation on the App

For instructions on related operations, see **Documents** on the SolaXCloud App.




Figure 11-2 Online help on the SolaXCloud App

#### NOTICE

 The pages above are taken from SolaXCloud App V6.1.0, which may change with software upgrade. The finally displayed pages are subject to the actual situations.

## 11.3 Operations on SolaXCloud Webpage

Open a browser and enter www.solaxcloud.com and then complete registration, login, plant creation and other operations according to the help document.




Figure 11-3 User guide on Web

# 12 Troubleshooting and Maintenance

## 12.1 Power off

- a. Turn off the system by **System ON/OFF** on LCD screen.
- b. Turn off the AC switch between the inverter and the power grid.
- c. Set the DC switch to OFF.
- Switch off the battery or the breaker, button, DC switch of the battery (see documentation of the battery manufacturer).

## **!** WARNING!

After the inverter is powered off, there may still be residual electricity and heat
which may cause electric shocks and body burns. Please wear personal protective
equipment (PPE) and start maintaining the inverter at least five minutes after power
off

## 12.2 Troubleshooting

This section lists the possible problems with the inverter, and provides information and procedures for identifying and resolving them. In case of any errors, check for the warnings or error messages on the system control panel or App, and then refer to the suggestions below. For further assistance, contact SolaX Customer Service. Please provide the model and SN of the inverter, and be prepared to describe the system installation details.

Table 12-1 Troubleshooting list

Error Code	Fault	Diagnosis and Solutions
IE 01	TZ Protect Fault	<ul> <li>Hardware protection fault</li> <li>Wait for a while to check if it returns to normal.</li> <li>Disconnect PV+, PV- and batteries, reconnect.</li> <li>If the system is in off-grid state, check if the power of EPS loads exceeds the maximum limit of the system or exceeds the current power supply of battery.</li> <li>If the system fails to restore to its normal state, contact SolaX for help.</li> </ul>
IE 02	Grid Lost Fault	Grid lost fault  Check the grid connection status.  Contact SolaX for help.

Error Code	Fault	Diagnosis and Solutions
IE 03	Grid Volt Fault	<ul> <li>Power grid overvoltage or undervoltage</li> <li>Wait a moment, if the utility returns to normal, the system will reconnect.</li> <li>Please check if the grid voltage is within normal range.</li> <li>Contact SolaX for help.</li> </ul>
IE 04	Grid Freq Fault	<ul> <li>Grid overfrequency or underfrequency</li> <li>Wait a moment, if the utility returns to normal, the system reconnects.</li> <li>Contact SolaX for help.</li> </ul>
IE 05	PV Volt Fault	PV voltage fault     Check the output voltage of the PV panel.     Check if the DC switch is OFF.     Contact SolaX for help.
IE 06	Bus Volt Fault	<ul> <li>Bus voltage fault</li> <li>Press the ESC key to restart the inverter.</li> <li>Check if the PV input open circuit voltage is in the normal range.</li> <li>Check if the power of half-wave load exceeds the system limit.</li> <li>Contact SolaX for help.</li> </ul>
IE 07	Bat Volt Fault	Battery voltage fault Check if the battery input voltage is within normal range. Contact SolaX for help.
IE 08	AC10mins Volt	<ul> <li>Grid voltage out of range in the last 10 minutes</li> <li>The system will return to normal if the grid returns to normal.</li> <li>Contact SolaX for help.</li> </ul>
IE 09	DCI OCP Fault	DCI overcurrent protection fault  Wait for a while to check if it's back to normal.  Contact SolaX for help.
IE 11	SW OCP Fault	<ul> <li>Software detection of overcurrent fault</li> <li>Wait for a while to check if it's back to normal.</li> <li>Shut down photovoltaic, battery and grid connections.</li> <li>Contact SolaX for help.</li> </ul>
IE 12	RC OCP Fault	RC overcurrent fault

Error Code	Fault	Diagnosis and Solutions	
IE 13	Isolation Fault	Isolation Fault or earth fault, is normally caused by insulation issues.  Please check the wire insulation for damage.  Wait for a while to check if it's back to normal.  Contact SolaX for help.	
IE 14	Temp Over Fault	Temperature out of range  Check if the ambient temperature exceeds the limit.  Contact SolaX for help.	
IE 15	Bat Con Dir Fault	Battery direction fault  Check if the battery cables are connected in the opposite direction.  Contact SolaX for help if it can not return to normal.	
IE 16	EPS Overload Fault	<ul> <li>EPS (Off-grid) overload fault</li> <li>Shutdown the high-power device and press the ESC key to restart the inverter.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	
IE 17	Overload Fault	On-grid mode overload fault  • Shutdown the high-power device and press the ESC key to restart the inverter.  • Contact SolaX for help if it can not return to normal.	
IE 18	BatPowerLow	Bat power low Shutdown the high-power device and press the ESC key to restart the inverter. Charge the battery to a level higher than the protection capacity or protection voltage. Contact SolaX for help.	
IE 19	BMS Lost	Battery communication lost  Check that the communication cable between the battery and the inverter are properly connected.  Contact SolaX for help if it can not return to normal.	
IE 20	Fan Fault	<ul> <li>Fan Fault</li> <li>Check for any foreign matter that may have caused the fan not to function properly.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	

Error Code	Fault	Diagnosis and Solutions
IE 21	Low TempFault	<ul> <li>Check if the ambient temperature is too low.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
IE 23	OtherDeviceFault	Other device fault  Contact SolaX for help.
IE 24	Missed CT Fault	CT fault  Check if the CT is connected correctly.  Contact SolaX for help.
IE 25	InterCommsFault	<ul> <li>Internal communication fault</li> <li>Restart the inverter.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
IE 26	INV EEPROM	<ul> <li>Inverter EEPROM fault</li> <li>Shut down photovoltaic, battery and grid, reconnect.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
IE 27	RCD Fault	<ul> <li>Residual current device fault</li> <li>Check the impedance of DC input and AC output.</li> <li>Disconnect PV+, PV - and batteries, reconnect.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
IE 28	Grid Relay Fault	<ul> <li>Electrical relay fault in Grid side</li> <li>Disconnect PV+, PV-, grid and batteries and reconnect.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
IE 29	EPS(Off-grid) Relay Fault	<ul> <li>EPS (Off-grid) relay fault</li> <li>Disconnect PV+, PV-, grid and batteries and reconnect.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
IE 30	PV ConnDirFault	PV direction fault  Check if the PV input cables are connected in the opposite direction.  Contact SolaX for help if it can not return to normal.
IE 31	Battery Relay	Charge relay fault Press the ESC key to restart the inverter. Contact SolaX for help if it can not return to normal.

Error Code	Fault	Diagnosis and Solutions	
IE 32	Earth Relay	<ul> <li>EPS (Off-grid) earth relay fault</li> <li>Press the ESC key to restart the inverter.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	
IE 35	Parallel Fault	<ul> <li>Check the connection of communication and PE cables, and check the settings for matching resistance.</li> <li>Contact SolaX for help.</li> </ul>	
IE 36	HardLimitFault	Australia power overrun fault     Check the power value in the hardware limit settings and increase the power value if necessary.     Contact SolaX for help.	
IE 101	PowerTypeFault	<ul> <li>Power type fault</li> <li>Upgrade the software and press the ESC key to restart the inverter.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	
IE 102	Port OC Warning	<ul> <li>EPS (Off-grid) port overcurrent fault</li> <li>Check if the EPS (Off-grid) load exceeds the system requirements, and press the ESC key to restart the inverter.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	
IE 103	Mgr EEPROM Fault	Manager EEPROM fault     Shut down photovoltaic ,battery and grid, and then reconnect.     Contact SolaX for help if it can not return to normal.	
IE 109	Meter Fault	<ul> <li>Meter fault</li> <li>Check if the meter is normal and is compatible with the inverter.</li> <li>Check if the communication cable is normal and properly connected.</li> <li>Check if the communication settings such as protocol, address and baud rate of the meter are consistent with those of the inverter.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	
IE 110	BypassRelayFlt	Bypass relay fault  Press the ESC key to restart the inverter.  Contact SolaX for help if it can not return to normal.	

Error Code	Fault	Diagnosis and Solutions	
IE 111	ARMParaComFlt	ARM parameter communication fault     Check that the communication cables of inverters are well connected and the baud rate of COMM setting of inverters are the same.     Contact SolaX for help if it can not return to normal.	
BE 01	BMS1_Exter_Err	Battery error - external communication fault	
DE UI	BMS2_Exter_Err	Contact SolaX for help.	
BE 02	BMS1_InterErr	Battery error - internal communication fault	
BE UZ	BMS2_InterErr	Contact SolaX for help.	
DE 07	BMS1_OverVolt	Over voltage in battery system	
BE 03	BMS2_OverVolt	Contact SolaX for help.	
DE O4	BMS1_LowerVolt	Low voltage in battery system	
BE 04	BMS2_LowerVolt	Contact SolaX for help.	
DE OF	BMS1_ChargeOCP	Battery fault - over charge fault	
BE 05	BMS2_ChargeOCP	Contact SolaX for help.	
BE 06	DischargeOCP1	Battery fault-discharge over current fault	
	DischargeOCP2	Contact SolaX for help.	
BE 07	BMS1_TemHigh	Over temperature in battery system	
BMS2_TemHigh		Contact SolaX for help.	
BE 08	BMS1_TempLow	Low temperature in battery system	
	BMS2_TempLow	Contact SolaX for help.	
BE 09	CellImblance1	Battery Unbalanced Fault	
	CellImblance2	Contact SolaX for help.	
BE 10	BMS1_Hardware	Battery slave control hardware protection fault	
	BMS2_Hardware	Contact SolaX for help.	
BE 11	BMS1_Circuit	Battery circuit fault	
	BMS2_Circuit	<ul><li>Restart the battery.</li><li>Contact SolaX for help.</li></ul>	
BE 12	BMS1_ISO_Fault	Battery insulation fault	
	BMS2_ISO_Fault	<ul> <li>Check that the battery is properly grounded ar restart the battery.</li> <li>Contact SolaX for help.</li> </ul>	

Error Code	Fault	Diagnosis and Solutions	
BE 13	BMS1_VolSen	Battery voltage sensor fault	
	BMS2_VolSen	Contact SolaX for help.	
BE 14	BMS1_TempSen	Temperature sensor fault	
	BMS2_TempSen	<ul><li>Restart the battery.</li><li>Contact SolaX for help.</li></ul>	
BE 15	BMS1_CurSen	Battery current sensor fault	
	BMS2_CurSen	Contact SolaX for help.	
BE 16	BMS1_Relay	Battery relay fault	
	BMS2_Relay	Contact SolaX for help.	
BE 17	TypeUnmatch1	Battery type fault	
	TypeUnmatch2	<ul> <li>Upgrade the battery BMS software.</li> <li>Contact SolaX for help.</li> </ul>	
BE 18	Ver Unmatch1	Battery version mismatch fault	
	Ver Unmatch2	<ul><li>Upgrade the battery BMS software.</li><li>Contact SolaX for help.</li></ul>	
BE 19	MFR Unmatch1	Battery manufacturer mismatch fault  Upgrade the battery BMS software.	
DL 13	MFR Unmatch2	Contact SolaX for help.	
DE 00	SW Unmatch1	Battery hardware and software mismatch faul	
BE 20	SW Unmatch2	Upgrade the battery BMS software.     Contact SolaX for help.	
DE 04	M&S Unmatch1	Battery master slave control mismatch fault	
BE 21	M&S Unmatch2	<ul><li> Upgrade the battery BMS software.</li><li> Contact SolaX for help.</li></ul>	
DE 22	CR NORespond1	Battery charging request no respond	
BE 22	CR NORespond2	<ul><li>Upgrade the battery BMS software.</li><li>Contact SolaX for help.</li></ul>	
	BMS1 SW Protect	Battery slave software protection failure	
BE 23	BMS2 SW Protect	<ul><li>Upgrade the battery BMS software.</li><li>Contact SolaX for help.</li></ul>	
DE 24	BMS1 536 Fault	Battery 536 fault	
BE 24	BMS2 536 Fault	Contact SolaX for help.	
BE 25	BMS2 SelfCheck	Battery self test fault	
DE 25	BMS2 SelfCheck	Contact SolaX for help.	

Error Code	Fault	Diagnosis and Solutions	
BE 26	BMS1 Tempdiff	Battery temperature sensor malfunction	
DE 20	BMS2 Tempdiff	Contact SolaX for help.	
DE 07	BMS1_BreakFault	Battery broken-line fault	
BE 27	BMS2_BreakFault	Contact SolaX for help.	
BE 28	BMS1_FlashFault	Battery flash fault	
DE 20	BMS2_FlashFault	Contact SolaX for help.	
BE 29	BMS1_Precharge	Battery precharge fault	
DE 29	BMS2_Precharge	Contact SolaX for help.	
DE 70	AirSwitchBreaker1	Battery air switch fault	
BE 30	AirSwitchBreaker1	<ul><li>Check if the battery breaker is off.</li><li>Contact SolaX for help.</li></ul>	
DE 74	BMS1_ClusterCom muCountMisMatch	Cluster communcation number mismatch  Contact SolaX for help.	
BE 31	BMS2_ClusterCom muCountMisMatch		
DE 70	BMS1_ClusterCom muAddr	Cluster communcation address duplication • Contact SolaX for help.	
BE 32	BMS1_ClusterCom muAddr		
/	Screen not on	<ul> <li>Check if the inverter correctly and normally connected to PV, battery or grid.</li> <li>Contact SolaX for help if the inverter is connected correctly.</li> </ul>	
	Abnormal sound on fan	<ul><li>Check if there is foreign objects stuck in the fan.</li><li>Contact SolaX for help.</li></ul>	
/	Screen on but no content display	Contact SolaX for help.	
/	LCD screen stuck in Wait state	Check if the input voltage of battery or PV is greater than 180 V.  If it meets the requirement, contact SolaX for help.  If the input voltage of battery or PV is less than	
/	No readings after CT connection	<ul> <li>180 V, check the corresponding connection.</li> <li>Check if CT is correctly clipped on the L wire</li> <li>Check if the arrow on the CT points at Grid.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>	

Error Code	Fault	Diagnosis and Solutions
I	No readings on Load (on App or Web)	<ul> <li>Check if the load is connected correctly.</li> <li>Check if the power of load on the LCD screen displays normally.</li> <li>Check if the monitoring module works normally.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
l	No readings on Grid (on App or Web)	<ul> <li>Check if the grid connection is normal.</li> <li>Check if the grid parameter on the LCD screen displays normally.</li> <li>Check if the monitoring module works normally.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
/	No readings on battery (on App or Web)	<ul> <li>Check if the battery is connected correctly.</li> <li>Check if the battery parameter on the LCD screen displays normally.</li> <li>Check if the monitoring module works normally.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
l	No Feedin data (on App or Web)	<ul> <li>Check if the meter/CT is connected correctly.</li> <li>Check if the meter/CT parameter on the LCD screen displays normally.</li> <li>Check if the monitoring module works normally.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
/	No data on App or Web	<ul><li>Check if the monitoring module works normally.</li><li>Contact SolaX for help.</li></ul>
/	No display on meter after power on	<ul> <li>If the meter connection is abnormal, reconnect them according to the wiring diagrams.</li> <li>Wait for the grid voltage to restore.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>
/	Abnormal electrical data on meter	<ul> <li>If the wiring is incorrect, reconnect them based or the wiring diagrams.</li> <li>Set the voltage and current ratio according to the setting steps of meter user manual.</li> <li>Contact SolaX for help if it can not return to normal.</li> </ul>

## 12.3 Maintenance

Regular maintenance is required for the inverter. Please check and maintain the following items based on the instructions below to ensure the optimal performance of the inverter. For inverters working in inferior conditions, more frequent maintenance is required. Please keep maintenance records.

## / WARNING!

- Only qualified person can perform the maintenance for the inverter.
- Only spare parts and accessories authorized by SolaX can be used for maintenance.

## 12.3.1 Maintenance routines

Table 12-2 Proposal of Maintenance

Item	Check notes	Maintenance interval
Electrical connection	<ul> <li>Ensure that all cables are firmly connected.</li> <li>Check the integrity of the cables, ensuring that there are no scratches on the parts touching the metallic surface.</li> <li>Verify that the sealing caps on idle terminals are not falling off.</li> </ul>	Every 12 months
Grounding reliability	Check if the grounding cables are firmly connected to the grounding terminals.     Use a ground resistance tester to test the grounding resistance from the inverter enclosure to the PE bar in the power distribution box.	Every 12 months
Heat sink	Check if there are foreign objects in the heat sink.	Every 12 months
General status of inverter	<ul> <li>Check if there is any damage on the inverter.</li> <li>Check if there is any abnormal sound when the inverter is running.</li> </ul>	Every 6 months

## 12.3.2 Upgrading Firmware

## **!** WARNING!

- Make sure that the type and format of the firmware file are correct. Do not modify the file name. Otherwise, the inverter may not work properly.
- Do not modify the folder name and file path where the firmware files are located, as this may cause the upgrade to fail.

## **!** WARNING!

 Before upgrading, ensure that the PV input voltage is higher than 180 V (preferably on sunny day), or that the battery SOC is higher than 20%, or the battery input voltage is higher than 180 V. Failure to meet one of these conditions may result in upgrade process failure.

### Upgrade preparation

- Prepare a USB drive (USB 2.0/3.0, <32 GB, FAT 16/32).</li>
- Check for the current firmware version of the inverter.
- Contact our service support for the update firmware file, and save it to the USB drive.
  - » For ARM file: XXX.XXXXX.X1\_VAST\_ARM\_VXXX.XX\_XXXX.bin
  - » For DSP file: XXX.XXXXX.X1\_VAST\_DSP\_VXXX.XX\_XXXX.bin
- Check the folder name and file path:



Figure 12-4 Folder name and path

## Upgrade steps

- Press and hold the Enter key on the inverter LCD for 5 seconds to enter the OFF mode.
- b. Remove the dongle from the Dongle terminal of the inverter by hand, and then insert the USB drive. The inverter will automatically display the **Upgrade Selection** interface. (For the position of Dongle terminal, see "8.1.1 Terminals of Inverter".)
- On the **Upgrade Selection** interface, select **ARM** or **DSP** based on the file type, and then tap **OK**.



d. Select and confirm the firmware version, and then tap the **Enter** key to start updating. ARM update takes about 20 seconds, and DSP update takes about 2 minutes.



 e. After the upgrade is completed, the LCD screen displays Upgrade Successful. If the upgrades fail, the LCD screen displays Upgrade failed.



## !\ CAUTION!

 If the ARM firmware upgrade fails or stops, do not unplug the USB drive. Power off the inverter, restart it, and then repeat the above upgrade steps.

## ( CAUTION!

If the DSP firmware upgrade fails or stops, perform operations below to troubleshoot:

- Check if the DC switch is turned off. If it is off, turn it on.
- (Recommneded) If the DC switch is already on, check if the battery and PV
  parameters in Main>System Status meets the upgrade requirements (The PV or
  battery input voltage should be larger than 180 V, or the battery SOC be higher than
  20%).
- Alternatively, select **Main > Mode Select > Manual > Forced Charge** to charge the battery. This process can help wake up the battery for DSP upgrade.

#### NOTICE

• If the LCD screen lags or freezes after the upgrade, turn off the DC switch, and then restart the inverter. Check if the inverter returns to normal. If not, contact us.

# 13 Decommissioning

## 13.1 Disassembling the Inverter

## **!** WARNING!

- Strictly follow the steps below to disassemble the inverter.
- Only use the dedicated disassembling tool for PV terminal delivered with the inverter to disassemble the PV connector.
- **Step 1:** Turn off the system by **System ON/OFF** to **OFF** state on LCD screen.
- **Step 2:** Disconnect the external AC breaker of the inverter.
- Step 3: Turn the DC switch to OFF.
- Step 4: Turn off the battery switch / button / breaker (if any). (See documents of battery)
- **Step 5:** Disconnect the PV connectors: Insert the disassembling tool for PV terminal (Part J) into the notch of PV connectors and slightly pull out the connectors.




Figure 13-5 Disassembling the PV connector

**Step 6:** (Optional) Disassembling the dustproof buckles: use disassembling tool for PV terminal to disassemble the dustproof buckles as shown below.




Figure 13-6 Disassembling the dustproof buckles

- **Step 7:** Slightly pull out the dongle module.
- **Step 8:** Disconnect the battery connectors: Insert the flat-head screwdriver into the notch of connectors and slightly pull the connectors.




Figure 13-7 Disassembling the Battery connector

**Step 9:** Disconnect the AC connector: Loosen the swivel nut, then loosen the metal cover screw on the connector enclosure. Slightly pull the connectors.




Figure 13-8 Removing AC connector

**Step 10:** Disconnect the COM connector: Loosen the swivel nut of the COM connector and loosen M3 screw of the communication connector by Phillips head screwdriver. Pinch the tabs on the sides of the connector and pull the connector at the same time to remove it.




Figure 13-9 Removing COM connector

- **Step 11:** Disconnect the PARALLEL and DRM connector: Loosen the swivel nut and cable support sleeve of the PARALLEL and DRM connector. Slightly pull the connectors.
- Step 12: Put the original teriminal caps on the terminals.
- Step 13: Unscrew the grounding screw by Allen key and remove the grounding cable.
- Step 14: (Optional) Unlock the anti-theft lock if you installed it.
- **Step 15**: Unscrew the M5 screw on the right side of inverter and vertically lift up the inverter to dismantle the inverter.




Figure 13-10 Unscrewing the M5 screws

**Step 16:** Unscrew the screws for fastening the wall mounting bracket and remove the wall mounting bracket if needed.

## 13.2 Packing the Inverter

• Use the original packaging materials if available.




Figure 13-11 Packing the inverter (Australian version with cable protective cover)




Figure 13-12 Packing the inverter (Australian version without cable protective cover)

- If the original packing material is not available, use the packing material which meets the following requirements:
  - » Suitable for the weight and dimension of product
  - » Convenient for transportation
  - » Can be sealed with adhesive tape

## 13.3 Disposing of the Inverter

Properly dispose of the inverter and accessories in accordance with local regulations on the disposal of electronic waste.

# 14 Technical Data

### • PV Input

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K		
Max. recommended PV power <sup>1</sup> [W]	10000	12000	16000	20000		
Max PV voltage [d.c. V]		6	00			
Nominal DC operating voltage [d.c. V]	360					
MPPT voltage range [d.c. V]		40-	560			
MPPT full power voltage range [d.c. V]	90-560	105-560	105-500	130-500		
Max. PV curent [d.c. A]	20/20/20	20/20/20	20/20/20/20	20/20/20/20		
Isc PV array short circuit [d.c. A]	25/25/25	25/25/25	25/25/25/25	25/25/25/25		
Start-up voltage [d.c. V]	50	50	50	50		
Max. inverter backfeed current to the array [d.c. V]	0	0	0	0		
No. of MPP trackers	3	3	4	4		
Strings per MPP trackers			1			

## • AC Output (On-grid)

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K		
Rated output apparent power [VA]	4999	6000	8000	9999		
Max. output apparent power [VA]	4999	6000	8000	9999		
Nominal AC voltage [a.c. V]		L/N/PE, 22	0/230/240			
Frequency [Hz]		50	/60			
Rated output current [a.c. A]	21.8	26.1	34.8	43.5		
Max. output continuous current [a.c. A]	21.8	26.1	34.8	43.5		
Current (inrush) (at 50µs) [a.c. A]		7	0			
Maximum output fault current (at 1ms) [a.c. A]	91					
Maximum output overcurrent protection [a.c. A]	140					
Power factor range	0.8 leading - 0.8 lagging					
Total harmonic distortion (THDi)	< 3 %					

### • AC Input

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K		
Max. apparent power [VA]	14500					
Nominal AC voltage [a.c. V]	L/N/PE, 220/230/240					
Frequency [Hz]	50/60					
Max. AC input current [a.c. A]	63					
Power factor range	0.8 leading - 0.8 lagging					

### Battery

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K		
Battery type	Lithium-ion battery					
Battery voltage range [d.c. V]	80-480					
Max. continuous charge/ discharge current [d.c. A] *	25 /25 for 2 strings 30 for 1 string					
Communication interface	CAN/RS485					
Reverse connection protection	Yes					

<sup>\*</sup>If two string batteries are connected to the two battery ports separately, the maximum charge / discharge of each battery is 25A; if one string battery is connected to only one battery port, the maximum is 30A; if one string battery is connected to both battery ports simultaneously (requires a separate purchase of a battery Y-cable), the maximum is 50A.

### • EPS Mode Output

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K		
Rated EPS apparent power [VA]	5000 (4999 for Australia)	6000	8000	10000 (9999 for Australia)		
Nominal EPS voltage [a.c. V]	L/N/PE, 220/230/240					
Frequency	50/60					
Rated EPS current [a.c. A]	21.8	26.1	34.8	43.5		
EPS (Off-grid) peak power [VA]	≤1.1Pn continuous operation; 1.1Pn-1.5Pn 60s; 1.5Pn-2Pn 10s; >2Pn report error immediately					
Switching time (typical value) [ms]	< 10					
Total harmonic distortion (THDv)	< 3 %					

### • Efficiency, Safety and Protection

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K		
Efficiency						
MPPT efficiency	99.9%	99.9%	99.9%	99.9%		
European efficiency	97.0%	97.0%	97.0%	97.0%		
Maximum efficiency	97.6%	97.6%	97.6%	97.6%		
Max. battery charge efficiency (PV to BAT) (@ full load)	97.0%	97.0%	97.0%	97.0%		
Max. battery discharge efficiency (BAT to AC) (@ full load)	97.0%	97.0%	97.0%	97.0%		
Safety and Protection						
Safety		EN/IEC62	109-1 / -2			
Grid monitoring	AS/NZS 4777, G99, EN 50549-10, BR140, IEC61727,IEC 61683, RD1699, NRS 097- 2-1, PEA/MEA, VFR2019					
DC SPD protection	Integrated					
AC SPD protection		Integ	rated			
Over/ under voltage protection		Y	es			
Grid protection		Y	es			
DC injection monitoring		Y	es			
Back feed current monitoring		Y	es			
Residual current detection	Yes					
Active anti-islanding method	Frequency Shift					
Over load protection		Y	es			
Over heat protection		Y	es			
Array insulation resistance detection	Yes					

### • General Data

Model	X1-VAST-5K	X1-VAST-6K	X1-VAST-8K	X1-VAST-10K			
Dimensions (W/H/D) [mm]		590*400*180					
Net weight [kg]		2	18				
Gross weight * [kg]		3	55				
Heat dissipation treatment		Natural	cooling				
Noise emission (typical) [dB]		<	35				
Storage temperature range [°C]		-40 t	o +65				
Operating ambient temperature range [ $^{\circ}$ C]		-35 to +60 (derating at 45)					
Humidity [%]		4 ~ 100 (Condensing)					
Altitude [m]		< 30	000				
Ingress protection		IP	66				
Protective class			I				
Cold standby consumption		< .	3W				
Overvoltage category		III(MAINS), II	I(PV, Battery)				
Pollution degree		III					
Installation mode	Wall mounted						
Inverter topology		Non-is	solated				
Communication interface	CT, Meter (optional), External control RS485, Pocket WiFi + LAN (Optional: Pocket Wifi 3.0/Pocket Wifi+4G), DRM, USB Upgrade						

<sup>\*</sup> The specific gross weight is subject to the actual situation of the whole machine, which may be a little different due to the influence of the external environment.

# 15 Appendix

## 15.1 Application of Generator

#### 15.1.1 Introduction of generator application

When utility power supply is unavailable, the system can seamlessly switch to the generator for power supply and continue the collaboration with the energy storage system to ensure the uninterrupted operation of the load.

In this case, the generator functions as the utility grid to supply power for the load, and the hybrid inverter converts the solar energy to electricity.

### 15.1.2 Notice for generator application

- Note 1: The generator should be equipped with an Auto Transformer Switch (ATS), enabling it to start automatically in the event of a power outage.
- Note 2: The rated output power of the generator should be greater than the sum
  of the load power and the battery charging power. If there are two inverters in
  parallel, the rated output power of the generator should be greater than the sum
  of the load power and the battery charging power of the two inverters.
- Note 3: If the rated output power of the generator is small and cannot meet the
  requirements of Note 2, the setting value of MaxChargePower can be changed
  in the Main>Setting>Advance Setting>ExternalGen to ensure that the generator
  power can meet the load and battery charging use at the same time.
- Note 4: The EPS load power cannot be greater than the battery discharge power
  to prevent the battery power from being unable to meet the EPS load after the
  generator shuts down and the inverter will report an **Overload fault** alarm. If two
  inverters are paralleled, the EPS load power shall be doubled.

#### 15.1.3 ATS control mode

In this operating mode, the generator functions as a substitute for the grid. There is no communication between the generator and the inverter, which means no wiring modifications are required (although the inverter cannot control the generator, either). The ATS working for the generator determines whether the generator should be turned on or off based on the status of the grid.

### Wiring connection diagram






Figure 15-1 ATS control wiring diagram

### Inverter settings for ATS control mode


a. Select Main>Setting>Advance Setting>ExternalGen>ATS Control.



- b. Set the relative parameters as below in accordance with actual needs.
  - » MaxChargePower: Maximum battery charging power from generator. (0-8000 W, 3000 W by default)



» Char&Disc Period: Including Forced Charg Period and Allowed Disc Period. Two periods can be set. These period settings are associated with the same settings under Working mode for no need to jump to working mode page to set the working period when using generator mode.



» Charge from Gen and Charge battery to: The SOC which allows the system charging from generator. (10-100%, 30% by default)



## 15.1.4 Dry contact mode

In this operating mode, users can intelligently control the system by establishing a dry contact connection between the inverter and the generator. It allows for adjustments to multiple settings so that the system can meet the requirements of different scenarios.

#### Wiring connection diagram




Figure 15-2 Dry contact wiring diagram

### Inverter connection for dry contact mode

Connection terminal-V2X terminal





Figure 15-3 Connection terminal for generator

Connection pins-Pin 7 and Pin 8

Table 15-1 Connection pins for generator

Application	1 1		/		/ Gen		erator	
Pin	1	2	3	4	5	6	7	8
Assignment	DI_A	DI_B	DO2_A	V2X_ CANH	V2X_ CANL	DO2_B	DO_A	DO_B


- Connection steps-Please refer to "COM communication connection wiring procedure" for specific wire making and connection.
- Inverter settings for dry contact mode
- a. Select Main>Setting>Advance Setting>ExternalGen>Dry Contact.



- b. Set the relative parameters in accordance with actual needs.
  - » MaxChargePower: Maximum battery charging power from generator. (0-8000 W, 3000 W by default).



» Start Gen Method: Reference SOC and Immediately can be selected. Reference SOC: Turn on/off generator according to the set Switch on/off SOC. Immediately: Turn on /off the generator when grid status changed.




Switch on/off SOC: the option is activated when you select Reference SOC for Start Gen Method. The inverter will turn on the generator when the battery reaches the set Switch on SOC and turn it off when the battery reaches the set Switch off SOC.




» MaxRunTime: Maximum operating time of generator. (1000 Min by default)



» MinRestTime: Minimum time interval for two consecutive starts to avoid frequent generator on and off.



» Char&Disc Period: Including Forced Charg Period and Allowed Disc Period. Two periods can be set. These period settings are associated with the same settings under Working mode for no need to jump to working mode page to set the working period when using generator mode.



» Allow Work: Allowed time period for generator operating. You can set the start time and end time.



» Charge from Gen and Charge battery to: The SOC which allows the system charging from generator. (10-100 % from generator, 30% by default)



## 15.2 Application of Adapter Box G2

### 15.2.1 Introduction of Adapter Box G2 application

With the SolaX Adapter Box G2, users can effectively utilize solar energy by commanding it to power their heat pump using settings available on the SolaX inverter and SolaXCloud. This intelligent integration allows for optimized solar self-consumption and ultimately helps in reducing electricity bills.

### 15.2.2 Wiring connection diagram




Figure 15-4 Adapter Box G2 wiring diagram

The inverter communicates with Adapter Box G2 via HEATPUMP. In case of excess power, the Adapter Box G2 can utilize it to heat the pump through the connection of dry contacts, SG Ready, or Analog output between the Adapter Box G2 and the heat pump. To power the Adapter Box G2, an external power adapter is required as the inverter itself cannot supply power to the Adapter Box G2.

### 15.2.3 Communication connection with inverter

Connection terminal-HEATPUMP terminal




Figure 15-5 Connection terminal for Adapter Box G2

Connection pins

Table 15-2 Pin-to-pin connection for inverter and Adapter Box G2

HEATPUMP te	erminal of inverter	RS485_INV terminal of Adapter Box G2			
Pin	Pin assignment	Pin	Pin assignment		
3	VCC	3	+12		
4	485A	4	RS485-A		
5	485B	5	RS485-B		
6	GND_COM	6	GND_COM		

 Connection steps-Please refer to "COM communication connection wiring procedure" for specific wire making and connection.





Figure 15-6 Connecting to Adapter Box G2

#### NOTICE

The communication cable between Adapter Box G2 and inverter can not exceed 100 m.

### 15.2.4 Settings for Adapter Box G2

- a. Select Main>Setting>Advance Setting>Internal485;
- Select the AdapBox G2 and set the Baud Rate and corresponding Address. The default Baud Rate is 19200.



#### NOTICE

- When two equipments need to be connected at the same time, the baud rate and address of the two equipments shall be set to the same.
  - c. Check the connection status.



#### NOTICE!

For specific wiring and setting procedures of Adapter Box G2, see Adapter Box G2
 User Manual.

## 15.3 Application of EV-Charger

### 15.3.1 Introduction of EV-Charger application

The EV-Charger is intended for charging electric vehicles. It should be installed in a fixed location and connected to the AC supply. The EV-Charger can communicate with other devices or systems (inverter, meter, CT, third-party charger management platform, etc.) to realize intelligent control of charging process.

### 15.3.2 Wiring connection diagram




Figure 15-7 EV-Charger wiring diagram

### 15.3.3 Communication connection with inverter

Connection terminal-EVC/RTU485 terminal




Figure 15-8 Connection terminal for EV-Charger

Connection pins

Table 15-3 Pin-to-pin connection for inverter and EV-Charger

EVC/RTU485	terminal of inverter	COM terminal of EV-Charger		
Pin	Pin assignment	Pin	Pin assignment	
4	485A	5	B1	
5	485B	4	A1	

• Connection steps-Please refer to "COM communication connection wiring procedure" for specific wire making and connection.





Figure 15-9 Connecting to EV-Charger

#### NOTICE

• The communication cable between EV-Charger and inverter can not exceed 100 m.

### 15.3.4 Setting for EV-Charger

- a. Select Main>Setting>Advance Setting>Internal485;
- Select the EV Charger and set the Baud Rate and corresponding Address. The default Baud Rate is 19200.




#### NOTICE

- When two equipments need to be connected at the same time, the baud rate and address of the two equipments shall be set to the same.
  - c. Check the connection status.



 d. You can enable Battery Charge EVC to allow the battery to discharge energy to EV-Charger through setting path: Main>Setting>Advance Setting>Battery Charge EVC.



#### NOTICE

 For specific wiring and setting procedures of EV-Charger, see X1/X3-EVC Series User Manual.

## 15.4 Application of DataHub

### 15.4.1 Introduction of DataHub application

SolaX DataHub can be connected to inverters through EVC/RTU485 to control the output power of the entire power station according to on-site requirements. Besides, it can work with SolaXCloud to monitor all inverters, allowing for real-time data display and device management. In the entire system, a maximum of 60 X1-VAST series inverters can be connected to the DataHub.

### 15.4.2 Wiring connection diagram




Figure 15-10 DataHub wiring diagram

### 15.4.3 Communication connection with inverter

Connection terminal-EVC/RTU485 terminal




Figure 15-11 Connectiong terminal for DataHub

Connection pins

Table 15-4 Pin-to-pin connection for inverter and DataHub

EVC/RTU485	terminal of inverter	RS485-1 ter	RS485-1 terminal of DataHub		
Pin	Pin assignment	Pin	Pin assignment		
4	485A	/	A+		
5	485B	/	B-		

 Connection steps-Please refer to "COM communication connection wiring procedure" for specific wire making and connection.




Figure 15-12 Connecting to DataHub

#### NOTICE

• The communication cable between DataHub and inverter can not exceed 100 m.

### 15.4.4 Settings for DataHub

- Select Main>Setting>Advance Setting>Internal485;
- b. Select the **DataHub** and set the **Baud Rate** and corresponding Address.



#### NOTICE

 The baud rate, communication protocol and verification method of the inverters connected to the same terminal of DataHub must be consistent, and the communication addresses of the inverters must be consecutive and not repeated.

#### NOTICE

• For specific wiring and setting procedures of DataHub, see *DataHub 1000 User Manual*.

## 15.5 Application of Micro-grid

### 15.5.1 Introduction of Micro-grid application

Micro-grid is the function that making hybrid inverter simulate the grid to active on-grid inverter during off-grid by connecting on-grid inverter to hybrid inverter's EPS terminal.

### 15.5.2 Wiring conenction diagram




Figure 15-13 Micro-grid wiring connection

### 15.5.3 Working modes

#### Grid on

- When PV is sufficient, the hybrid and on-grid inverters power the common and EPS loads together. When there is surplus energy on the on-grid inverter, it will also charge the battery.
- When PV is insufficient, the hybrid, on-grid inverter and grid power all the loads.

### Grid off

In this case, the hybrid inverter will simulate the grid so as to make the on-grid inverter work. Hybrid and on-grid inverter will power the EPS loads together. If there is surplus energy, it will charge the battery.

#### NOTICE

In EPS mode, due to limited battery charging power, the hybrid inverter will increase
the EPS output frequency to restrict and shut down the on-grid inverter, ensuring the
stable operation of the entire system. In this period, the on-grid inverter may report a
Grid frequency Fault which is a normal phenomenon.

### Notice for micro-grid application

- Any brand of on-grid inverter that supports "frequency adaptation"
- On-grid inverter output power < Max hybrid inverter EPS output power</li>
- On-grid inverter output power < Max battery charging power

#### NOTICE

 Since X1-VAST series inverter is unable to control the output power of on-grid inverter in grid connection mode, the series inverter can not achieve zero export when loads power + battery charging power < on-grid inverter output power.</li>

#### 15.5.4 Cable connection (Hybrid inverter)

Please refer to "8.3 AC Connection" for Grid and EPS connection on X1-VAST series inverter.

### 15.5.5 Cable connection (On-grid inverter)

Please connect the AC cable of on-grid inverter to the EPS terminal of X1-VAST series inverter. Please refer to the user manual of specific on-grid inverter.

### 15.5.6 Cable connection (Meter)

To detect and monitor the power data generated from the on-grid inverter, install a meter on the on-grid inverter side. Otherwise, the relevant power data of on-grid inverter can not be monitored.




Figure 15-14 Connection diagram of Meter on EPS terminal

### Pin assignment

Table 15-5 Pin assignment for meter and CT

Application	For CT1		For meter		For CT2			
Pin	1	2	3	4	5	6	7	8
Assignment	CT1_1	GND_ CON	CT2_1	METER _485A	METER _485B	CT2_2	GND_ CON	CT1_2

 Meter/CT connection steps-Please refer to "COM communication connection wiring procedure" and meter/CT user manual for specific connection steps.

## 15.6 Application of Parallel Function

### 15.6.1 Introduction of parallel application

The series inverters supports parallel operation in both Grid and EPS modes. It supports up to 2 units in the parallel system.

### 15.6.2 Notice for parallel application

- All inverters should be of the same software version.
- For optimal efficiency, it is recommended that the two inverters have the same model, and are connected to batteries of the same model and quantity.
- In parallel system, there are three status: Free, Slave and Master.

	Table 15-6 Three status		
Free	Only if no inverter is set as a <b>Master</b> , the two inverters are in <b>Free</b> mode in the system.		
Slave	Once one inverter is set as a <b>Master</b> , the other inverter will enter <b>Slave</b> mode automatically. <b>Slave</b> mode can not be changed from other modes by LCD setting.		
Master	When one inverter is set as a <b>Master</b> , this inverter enters <b>Master</b> mode. <b>Master</b> mode can be changed to <b>Free</b> mode.		

Table 15-6 Three status

- Master inverter has an absolute lead in the parallel system to control slave inverter's energy management and dispatch control. Once master inverter has some error and stop working, slave inverter will be stop simultaneously. But master inverter is independent of slave inverter to work and will not be affected by slave inverter's fault.
- Overall system will be running according to master inverter's setting parameters, and most setting parameters of slave inverter will be kept but not be cancelled.
- Once slave inverter exits from the system and be running as an independent unit (the network cable is disconnected simultaneously), its all setting will be reactivated.
- The parallel system is extremely complex and requires a large number of cables to be connected. Therefore, the cables must be connected in the correct wire sequence. Otherwise, any small mistake can lead to system failure.
- The communication cable length should not exceed 10 m.

## 15.6.3 System wiring diagram




Figure 15-15 System wiring diagram

## 15.6.4 System wiring procedure

## Power cable wiring-Grid and EPS terminal

- a. Grid termial of Master and Slave inverter: L connects to L and N connects to N,
- b. EPS termial of Master and Slave inverter: L connects to L and N connects to N,
- c. PE cable connects to the E-BAR nearby.




Figure 15-16 Power cable wiring

### Communication cable wiring-COM terminal and COM terminal

- a. Use standard network cables for Master-Slave inverter connection.
- b. Master inverter Parallel connects to Slave inverter Parallel.
- c. Meter/CT connects to Meter/CT terminal of the Master inverter. Please refer to "COM communication connection wiring procedure".




Figure 15-17 Communication wiring

### 15.6.5 Settings for parallel connection

#### Parallel setting

Setting path: Main>Setting>Advance Setting>Parallel Setting.

#### How to build the parallel connection

a. Turn on the power of the entire system, find the inverter which needs to be set as Master and connect the meter to Master inverter, enter the setting page of the Master inverter LCD screen, select the **Parallel Setting**, and select **Master**; then enter the **Resistance Switch** and set it to **ON**;




 Find the last slave in the parallel system and enter the setting page of the inverter LCD screen and set the Resistance Switch to ON.



#### How to remove the parallel connection

a. Find the inverter which needs to be set as Free. Select the Parallel Settings and select Free for the inverter.



b. Disconnect all the network cables on the Parallel-1 and Parallel-2 port.

#### NOTICE

- If a slave inverter is set to **Free** mode but not disconnect the network cable, this inverter will return to **Slave** mode automatically.
- If a slave inverter is disconnected with master inverter but not be set to Free mode, this slave inverter will stop working and prompt ParallelFault.

## Parallel display

Displaying path: Main>Parallel Status

#### NOTICE

• Once inverter enters parallel system, the **Today** yield will be replaced by **Parallel**.

In **Parallel Status** interface, the whole system power and individual slave inverter power can be obtained in **Parallel Status** interface of master inverter. The number displayed in the **Parallel Status** interface refers to the total number of online inverters, for example two inverters in parallel in the below figure.



## 15.7 Application of Meter/CT

#### 15.7.1 CT/Meter Connection Scenarios

X1-VAST inverter series can be connected to a CT, a direct-connected meter, or a CT-connected meter. It also supports a Meter 2 function for you to monitor another power generation equipment at home.

Followings are the detailed wiring and setting procedures of these scenarios. For wiring procedure of the inverter CT/Meter port, see "Meter/CT wiring procedure".

#### 15.7.2 Connection of CT

#### NOTICE

- Do not place the CT on the N wire or ground wire.
- Do not place CT on the N line and L line at the same time.
- Do not place the CT on non-insulated wires.
- The cable length between CT and inverter should not exceed 100 meters.
- After CT is connected, prevent the CT clip from falling off. It is recommended to wrap the CT clip around in circles with insulating tape.

#### NOTICE!

• The CT referred to in this section is the CT delivered with the inverter.




Figure 15-1 System wiring with CT

<sup>\*</sup> The arrow on the CT must point at the public grid.

<sup>\*</sup>The emergency load is connected to the EPS terminal of the inverter, which is not shown in the diagram.

### Wiring Procedure

**Step 1:** Clip the CT to the L cable of the grid.

Make sure the arrow on the CT is pointing to the grid side from the inverter.




Figure 15-2 Clipping CT to grid cables

**Step 2:** Use the RJ45 coupler to connect the extension communication cable and the CT.




Figure 15-3 Connecting the inverter to the CT

### **Setting Procedure**

After connecting CT to the inverter, you need to enable it on the inverter before it can be used.

Select Advance Settings > Meter/CT Setting, and then select CT.

You can check the CT connection status in **Meter/CT Check**. For details, see "Meter/CT Check".



Figure 15-4 Setting CT for the inverter

### 15.7.3 Connection of Direct-connected Meter

#### NOTICE

• SolaX DDSU666 is used for example.




Figure 15-3 System wiring with SolaX DDSU666

<sup>\*</sup>Terminal 1 and 2 of the meter must be connected to the grid side, and terminnal 3 and 4 be connected to the inverter side of the system. Otherwise, the system power data might be misread.

<sup>\*</sup>The emergency load is connected to the EPS terminal of the inverter, which is not shown in the diagram.

### Meter Terminal Definition

Table 15-1 Terminal defintion of DDSU666

Terminal No.	Definition	Description
1, 3	UL	Voltage input and output terminal, connected to the L wire
2, 4	UN	Phase N voltage input and output terminal, connected to the N wire
24	RS485A	RS485 terminal A
25	RS485B	RS485 terminal B

### Wiring Procedure

**Step 1:** Strip around 10 mm wire insulation off the L and N cables, and then connect the L wire to terminal 1 and 3, and the N wire to terminal 2 and 4 in sequence.




Figure 15-5 Connecting DDSU666 to the grid

**Step 2:** Strip 15 mm wire insulation off the other end of the communication cable.




Figure 15-6 Stripping communication cable for meter

**Step 3:** Connect the conductors to terminal 24 and 25 of the meter.




Figure 15-7 Connecting inverter to DDSU666

### **Setting Procedure**

After connecting meter to the inverter, you need to enable it on the inverter before it can be used.

Select Advance Settings > Meter/CT Setting, and then select Meter.

You can check the meter connection status in **Meter/CT Check**. For details, see "Meter/CT Check".




Figure 15-8 Setting meter for the inverter (1)

### 15.7.4 Connection of CT-connected Meter

#### NOTICE

- SolaX DDSU666-CT is used for example.
- The CT referred to in this section is the CT delivered with DDSU666-CT.




Figure 15-9 System wiring with SolaX DDSU666-CT

<sup>\*</sup>The arrow on the CT must point at the inverter side.

<sup>\*</sup>Terminal 1 and 2 of the meter must be connected to the grid side. Terminal 9 must be connected to the S1 wire of the CT, and terminal 10 be connected to the S2 wire of the CT. Otherwise, the system power data might be misread.

<sup>\*</sup>The emergency load is connected to the EPS terminal of the inverter, which is not shown in the diagram.

#### Meter Terminal Definition

Table 15-2 Terminal defintion of SolaX DDSU666-CT

Terminal No.	Definition	Description
1	UL	Voltage input terminal, connected to the L wire
2	UN	Phase N voltage input terminal, connected to the N wire
9	*	Current input terminal, connected to S1 wire of CT
10	I	Current output terminal, connected to S2 wire of CT
24	RS485A	RS485 terminal A
25	RS485B	RS485 terminal B

### Wiring Procedure

- **Step 1:** Strip around 10 mm wire insulation off the L and N cables, and then connect L and N wires respectively to terminal 1 and 2 of the meter.
- **Step 2:** Clip the CT onto the L wire in the direction from gird to inverter.
- Step 3: Connect S1 wire of the CT to terminal 9, and S2 wire of the CT to terminal 10.




Figure 15-10 Connecting DDSU666-CT to the grid

**Step 4:** Strip 15 mm wire insulation off the other end of the communication cable.




Figure 15-11 Stripping communication cable for meter

**Step 5:** Connect the conductors to terminal 24 and 25 of the meter.




Figure 15-12 Connecting inverter to meter

### **Setting Procedure**

After connecting meter to the inverter, you need to enable it on the inverter before it can be used.

Select Advance Settings > Meter/CT Setting, and then select Meter.

You can check the meter connection status in **Meter/CT Check**. For details, see "Meter/CT Check".




Figure 15-13 Setting meter for the inverter (2)

#### 15.7.5 Connection of Two Meters

If you have another power generation equipment (such as an inverter) at home and wants to monitor both equipment, our inverter provides a Meter 2 Communication function to monitor the other power generation equipment.

#### NOTICEL

- For connecting CT and meter, or connecting two meters, prepare an RJ45 splitter adapter and a proper waterproof enclosure for it in advance.
- For X1-VAST inverter series, Meter 1 and meter 2 can both be CT, direct-connected meter and CT-connected meter. The following diagrams use double CTs and double direct-connected meters for example.




Figure 15-14 Connecting to double CTs




Figure 15-15 Connecting to double direct-connected meters

### Wiring Procedure

- **Step 1:** Follow the above steps to connect the meter, CT and inverter.
- **Step 2:** Connect the RJ45 terminals to the RJ45 splitter adapter.

### **Setting Procedure**

After connecting the CT and meter to the inverter, you need to set parameters on the inverter LCD before the they can work normally for the system.

Step 1: Select Advance Settings > Meter/CT Setting.

Step 2: Set the Meter/CT:

» Case 1: Double CTs are connected respectively to the position of Meter 1 and Meter 2. In this case, you only need to select CT, and the inverter will identify the CTs automatically.




Figure 15-16 Setting CT for the inverter

» Case 2: CT and Meter 2 are connected (CT for SolaX inverter, Meter 2 for another power generation equipment). CT is set by default. Check whether the address and direction of Meter2 are set based on actual connection.



Figure 15-17 Selecting CT and set Meter2 data

» Case 3: Meter 1 and Meter 2 are connected (Meter 1 for SolaX inverter, Meter 2 for another power generation equipment). Select **Meter** and enble the Meter function. Check whether the address and direction of Meter 1 and Meter 2 are set based on actual connection.



Figure 15-18 Selecting meter and set Meter 1 and Meter 2 data

### **Related Operation**

#### Setting Meter/CT Check

• **Installation Check**: It is for checking whether the meter/CT has been correctly connected. It is vital to the normal function of the whole system. Therefore, we recommend performing installation check after connecting the meter/CT.

Select Meter/CT Setting > Meter/CT Check, and then enable Installation Check.

The system will perform meter/CT check immediately after you enable it, and then automatically restores to the disabled status after the check completes.



 Cyclic Check: It is for periodically checking whether the meter/CT is in good condition when the inverter is running.

Select Meter/CT Setting > Meter/CT Check, and then enable Cyclic Check.

Once Cyclic Check is enabled, the system will check the meter/CT status periodically based on the defined cycle.



Figure 15-19 Checking CT/Meter status

#### Setting WI-BR HP Mode

Here you can disable the WI-BR HP Mode, enable is by default. By default, the
transmitter and receiver of the wireless meter have a transmission frequency of
24 db. When the WI-BR HP Mode is disabled, the transmission frequency is 14 db.



**Setting Meter1 Config** (It is displayed only when SolaX meter is detected.)

- CT Ratio: Current sampling ratio. Range: 100~1000; Default: 100
- VT Ratio: Voltage sampling ratio. Range: 100~1000; Default: 100
- Password: Set the password of the Meter1.
- **Baud Rate**: Selectable baud rate: 9600, 19200, 38400, 115200. The default value is 9600, when you change the baud rate, it is to modify the communication transmission speed of the meter, which may be disconnected from the meter.

Setting Meter2 Config (It is displayed only when SolaX meter is detected.)

- CT Ratio: Current sampling ratio. Range: 100~1000; Default: 100
- VT Ratio: Voltage sampling ratio. Range: 100~1000; Default: 100
- **Password:** Set the password of the Meter2.
- **Baud Rate**: Selectable baud rate 9600, 19200, 38400, 115200. The default value is 9600, when you change the baud rate, it is to modify the communication transmission speed of the meter, which may be disconnected from the meter.

# **Contact Information**

# UNITED KINGDOM

Unit C-D Riversdale House, Riversdale Road, Atherstone, CV9 1FA

+44 (0) 2476 586 998

service.uk@solaxpower.com

## C TURKEY

Fevzi Çakmak mah. aslım cd. no 88 A Karatay / Konya / Türkiye

service.tr@solaxpower.com

## **USA**

3780 Kilroy Airport Way, Suite 200, Long Beach, CA, US 90806

+1 (408) 690 9464

info@solaxpower.com

## POLAND

WARSAW AL. JANA P. II 27. POST

+48 662 430 292

service.pl@solaxpower.com

## ITALY

+39 011 19800998

support@solaxpower.it

# C PAKISTAN

service.pk@solaxpower.com

# 🍀 AUSTRALIA

21 Nicholas Dr, Dandenong South VIC 3175

+61 1300 476 529

service@solaxpower.com.au

# GERMANY

Am Tullnaupark 8, 90402 Nürnberg, Germany

+49 (0) 6142 4091 664

service.eu@solaxpower.com
service.dach@solaxpower.com

# NETHERLANDS

Twekkeler-Es 15 7547 ST Enschede

+31 (0) 8527 37932

service.eu@solaxpower.com
service.bnl@solaxpower.com

# SPAIN

+34 9373 79607

tecnico@solaxpower.com

## BRAZIL

+55 (34) 9667 0319

✓ info@solaxpower.com



service.za@solaxpower.com



# SolaX Power Network Technology (Zhejiang) Co., Ltd.

Add.: No. 278, Shizhu Road, Chengnan Sub-district, Tonglu County, Hangzhou, Zhejiang, China

E-mail: info@solaxpower.com

